Use and care manual

BO 480/481 613

Built-in oven

Table of Contents

▲ Safety Definitions	3
IMPORTANT SAFETY INSTRUCTIONS	4
Proper Installation and Maintenance	4
Fire Safety	5
Burn Prevention	6
Child Safety	7
Cleaning Safety	7
Cookware Safety	7
Proposition 65 Warning	8
Causes of damage	9
Environmental protection	9
Tips for saving energy	9
Familiarizing yourself with your appliance	10
Oven	10
Displays and controls	11
Symbols	11
Colors and display	11
Standby	12
Activate appliance	12
Automatic door opening	12
Additional information i and i [®]	12
Cooling fan	12
Program selection positions	13
Accessories	14
Special accessories	15
Before using the appliance for the first time	15
Setting the language	15
Setting the time format	15
Setting the time	15
Setting the date format	16
Setting the date	16
Setting the temperature unit	16
Completing initial set-up	16
Heating up the oven	16
Cleaning accessories	16
Operating the appliance	16
Oven interior	16
Inserting the rack	16
Turning on	17
Quick heat	17
Safety shut-off	17

Timer functions	18
Launching the timer menu	18
Timer	18
Stopwatch	18
Cooking time	19
End of cooking time	20
Sabbath mode and Yom Tov mode	21
Sabbath mode	21
Yom Tov mode	21
Automatic programs	22
Information on the settings	22
Selecting a dish	22
Applying settings for dishes	23
Calling up the last automatic programs used	23
Personal recipes	24
Recording a recipe	24
Programming a recipe	24
Entering a name	25
Starting a recipe	25
Change recipe	25
Deleting a recipe	25
Core temperature probe	26
Inserting the core temperature probe into the food	26
Setting the core temperature	27
Core temperature guidelines	28
Rotisserie spit	29
Preparation	29
Switching on the rotisserie spit	30
Switching off the rotisserie spit	30
Roasting function	31
Childproof lock	31
Activating the child lock	31
Deactivating the child lock	31
Home Connect	32
Setting Up	32
Remote Start	33
Home Connect settings	33
Remote Diagnostics	34
Information on Data Protection	34
Declaration of Conformity	34
Wi-Fi® Module	34

Basic settings	36
Cleaning and maintenance	39
	39
Cleaning agents Removing the plug-in grid	40
Pyrolysis (self-cleaning)	40
Preparing the pyrolytic self-cleaning feature	41
Starting the pyrolytic self-cleaning function	41
Cleaning the Accessories with the Pyrolytic Self	J
Feature	42
Troubleshooting	42
Power cut	42
Demo mode	42
Replacing the oven lamp	43
Customer service	44
Tables and tips	45
Vegetables	46
Side dishes and dishes	47
Fish	50
Meat	50
Poultry	53
Grilling and roasting	54
Baked goods	56
Dough proving (leaving to rise)	61
Desserts	61
Defrosting	62
Preserving	63
Disinfecting	63
Drying	63
Baking stone	64
Roasting dish	65
Acrylamide in foodstuffs	66

▲ Safety Definitions

▲ WARNING

This indicates that death or serious injuries may occur as a result of non-observance of this warning.

A CAUTION

This indicates that minor or moderate injuries may occur as a result of non-observance of this warning.

NOTICE

This indicates that damage to the appliance or property may occur as a result of non-compliance with this advisory.

Note: This alerts you to important information and/or tips.

Additional information on products, accessories, replacement parts and services can be found at www.gaggenau.com and in the online shop www.gaggenau.com/zz/store



READ AND SAVE THESE INSTRUCTIONS

lack

WARNING

When properly cared for, your new appliance has been designed to be safe and reliable. Read all instructions carefully before use. These precautions will reduce the risk of burns, electric shock, fire, and injury to persons. When using kitchen appliances, basic safety precautions must be followed, including those in the following pages.

Proper Installation and Maintenance

Have the installer show you the location of the circuit breaker or fuse. Mark it for easy reference.

This appliance must be properly installed and grounded by a qualified technician. Connect only to properly grounded outlet. Refer to Installation Instructions for details.

This appliance is intended for normal family household use only. It is not approved for outdoor use. See the Statement of Limited Product Warranty. If you have any questions, contact the manufacturer.

Do not store or use corrosive chemicals, vapors, flammables or nonfood products in or near this appliance. It is specifically designed for use when heating or cooking food. The use of corrosive chemicals in heating or cleaning will damage the appliance and could result in injury.

Do not operate this appliance if it is not working properly, or if it has been damaged. Contact an authorized servicer.

Do not obstruct oven vents.

Do not repair or replace any part of the appliance unless specifically recommended in this manual. Refer all servicing to an authorized servicer.



WARNING

Risk of burns!

To avoid risk of injury, turn off the interior light before cleaning the oven to allow the bulbs to cool down. The bulbs can become very hot when switched on. Keep the light off while cleaning the oven.



WARNING

Make sure the appliance and lights are cool and power to the appliance has been turned off before replacing the light bulb(s). Failure to do so could result in electrical shock or burns. The lenses (if equipped) must be in place when using the appliance. The lenses (if equipped) serve to protect the light bulb from breaking. The lenses (if equipped) are made of glass. Handle carefully to avoid breaking. Broken glass can cause an injury.



READ AND SAVE THESE INSTRUCTIONS

WARNING

Light socket is live when door is open if main power supply is not turned off.

Fire Safety



WARNING

NEVER cover any slots, holes or passages in the oven bottom or cover an entire rack with materials such as aluminum foil. Doing so blocks air flow through the oven. Aluminum foil linings may also trap heat, causing a fire hazard.

If materials inside an oven or warming drawer should ignite, keep door closed. Turn off the appliance and disconnect the circuit at the circuit breaker box.



▲ WARNING

Use this appliance only for its intended use as described in this manual. NEVER use this appliance as a space heater to heat or warm the room. Doing so may result in overheating the appliance. Never use the appliance for storage.

Always have a working smoke detector near the kitchen.

In the event that personal clothing or hair catches fire, drop and roll immediately to extinguish flames.

Have an appropriate fire extinguisher available, nearby, highly visible and easily accessible near the appliance.

Smother flames from food fires other than grease fires with baking soda. Never use water on cooking fires.

WARNING

TO REDUCE THE RISK OF INJURY TO PERSONS IN THE EVENT OF A GREASE FIRE, OBSERVE THE **FOLLOWING:**

- 1. SMOTHER FLAMES with a closefitting lid, cookie sheet, or metal tray, then turn off the burner. BE CAREFUL TO PREVENT BURNS. If the flames do not go out immediately, EVACUATE AND CALL THE FIRE DEPARTMENT.
- 2. NEVER PICK UP A FLAMING PAN - You may be burned.
- 3. DO NOT USE WATER, including wet dishcloths or towels - a violent steam explosion will result.
- 4. Use an extinguisher ONLY if:
 - You know you have a Class ABC extinguisher, and you already know how to operate it.
 - The fire is small and contained in the area where it started.
 - The fire department is being
 - You can fight the fire with your back to an exit.



READ AND SAVE THESE INSTRUCTIONS

Burn Prevention

DO NOT TOUCH HEATING ELEMENTS OR INTERIOR SURFACES OF OVEN -Heating elements may be hot even though they are dark in color. Interior surfaces of an oven become hot enough to cause burns. During and after use, do not touch, or let clothing, potholders, or other flammable materials contact heating elements or interior surfaces of oven until they have had sufficient time to cool. Other surfaces of the appliance may become hot enough to cause burns. Among these surfaces are oven vent openings, surfaces near these openings and oven doors.

Exercise caution when opening the appliance. Standing to the side, open the door (or drawer) slowly and slightly to let hot air and/or steam escape. Keep your face clear of the opening and make sure there are no children or pets near the unit. After the release of hot air and/or steam, proceed with your cooking. Keep doors shut unless necessary for cooking or cleaning purposes. Do not leave open doors unattended.



WARNING

Risk of burns!

The inside of the appliance door becomes very hot during operation. Always open the appliance door as far as it will go. Ensure that the appliance door does not swing back. Avoid contact with the inside of the appliance door.

Do not heat or warm unopened food containers. Build-up of pressure may cause the container to burst and cause injury.

Use caution when cooking foods with high alcohol content (e.g. rum, brandy, bourbon) in the oven. Alcohol evaporates at high temperatures. There is a risk of burning as the alcohol vapors may catch fire in the oven. Use only small quantities of alcohol in foods, and open the oven door carefully.

Always place oven racks in desired location while oven is cool. Always use oven mitts, when the oven is warm. If a rack must be moved while oven is hot, do not let potholder contact the heating elements.



A CAUTION

To avoid possible injury or damage to the appliance, ensure rack is installed exactly per installation instructions and not backwards or upside down.

Always use dry potholders. Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholder touch hot heating elements. Do not use a towel or other bulky cloth.

Secure all loose garments, etc. before beginning. Tie long hair so that it does not hang loose, and do not wear loose fitting clothing or hanging garments, such as ties, scarves, jewelry, or dangling sleeves.



READ AND SAVE THESE INSTRUCTIONS

Child Safety

When children become old enough to use the appliance, it is the responsibility of the parents or legal guardians to ensure that they are instructed in safe practices by qualified persons.

Do not allow anyone to climb, stand, lean, sit, or hang on any part of an appliance, especially a door, warming drawer, or storage drawer. This can damage the appliance, and the unit may tip over, potentially causing severe injury.

Do not allow children to use this appliance unless closely supervised by an adult. Children and pets should not be left alone or unattended in the area where the appliance is in use. They should never be allowed to play in its vicinity, whether or not the appliance is in use.



A CAUTION

Items of interest to children should not be stored in an appliance, in cabinets above an appliance or on the backsplash. Children climbing on an appliance to reach items could be seriously injured.

Cleaning Safety

IMPORTANT SAFETY NOTICE: The California Safe Drinking Water and Toxic Enforcement Act requires the Governor of California to publish a list of substances known to the state to cause cancer, birth defects or other reproductive harm, and requires businesses to warn customers of potential exposure to such substances.

The burning of gas cooking fuel and the elimination of soil during self-cleaning can generate some by-products which are on the list. To minimize exposure to these substances, always operate this unit according to the instructions contained in this booklet and provide good ventilation.

When self-cleaning, confirm that the door locks and will not open. If the door does not lock, do not run Self-Clean. Contact service.

Wipe out excessive spillage before selfcleaning the oven.

Birds have very sensitive respiratory systems. Keep pet birds out of the kitchen or other rooms where kitchen fumes could reach them. During selfclean, fumes are released that may be harmful to birds. Other kitchen fumes such as overheating margarines and cooking oils may also be harmful.

Keep oven free from grease build up.

Cookware Safety

NOTICE

Do not place food directly on oven bottom.

Follow the manufacturer's directions when using cooking or roasting bags.



CAUTION

Do not leave food or cooking utensils, etc., in the oven during the self-cleaning mode of operation.



READ AND SAVE THESE INSTRUCTIONS

Do not clean parts or accessories in the self-clean oven.



WARNING

Risk of electric shock!

Use of a wrong core temperature probe can damage the insulation. Use only the core temperature probe intended for this appliance.

Proposition 65 Warning:

This product may contain a chemical known to the State of California, which can cause cancer or reproductive harm. Therefore, the packaging of your product may bear the following label as required by California:

STATE OF CALIFORNIA PROPOSITION 65 WARNING:

⚠ WARNING

Cancer and Reproductive Harm - www.P65Warnings.ca.gov

Remote Operation

This appliance is configurable to allow remote operation at any time. Do not store any flammable materials or temperature sensitive items inside, on top or near surface units of the appliance.

WARNING

While cooking food items, small amounts of certain by-products, such as particulate matter / soot, can be released. To minimize exposure to these substances:

- Always ensure proper ventilation by using an appropriate ventilation fan or hood vented to the outside and/or an open window.
- ► Always operate the unit according to the instructions in this manual.

WARNING

Overheated materials can cause fire or burns and may produce potentially harmful smoke or fumes.

- To prevent overheating, turn ventilation hood ON when heating grease, fats or frying using medium to high heat settings.
- Avoid heating empty pots and pans.
- Do not allow pans to boil dry.
- Do not allow aluminum foil, plastic, paper, or cloth to come in contact with a hot surface element, burner, or grate.

Causes of damage

NOTICES:

- Accessories, foil, baking paper or cookware on the bottom of the oven interior: do not place any accessories on the bottom of the oven interior. Do not line the bottom of the oven interior with any type of foil or baking paper. Do not place cookware on the bottom of the oven interior when a temperature above 122°F (50 °C) is set. This produces a build-up of heat. Baking and roasting times are no longer correct and the enamel is damaged.
- Water in the hot oven interior: Never pour water into the hot oven interior. Steam is produced. Damage to the enamel can arise due to the temperature change.
- Do not leave moist groceries in a closed oven for an extended period of time. It can lead to corrosion inside the oven.
- Fruit juice can leave stains in the oven. Always remove fruit juice immediately when safe to touch, and wipe up first with a damp and then a dry cloth.
- Cooling with the appliance door open: only allow the oven cavity to cool when it is closed. Even if the appliance door is only open a little, front panels of adjacent units could be damaged over time.
- Highly soiled door seal: the appliance door will no longer close properly during operation if the door seal is highly soiled. Adjoining furniture fronts may be damaged. Always keep the door seal clean.
- Appliance door as a seat or storage surface: do not stand, sit or hang on the appliance door. Do not place any cookware or accessories on the appliance door.
- Inserting accessories: depending on the appliance type, accessories can scratch the door pane when closing the appliance door. Always slide accessories fully into the oven interior.
- Do not hold or carry the appliance by the door handle. The door handle cannot carry the weight of the device and could break off.

Environmental protection

Unpack the appliance and dispose of the packaging in an environmentally friendly manner.


Tips for saving energy

- Open the appliance door as little as possible while cooking, baking or roasting.
- Use dark, black-painted or enameled baking forms. These absorb the heat particularly well.
- It is best to bake several cakes in succession. The oven is still warm. This shortens the baking time for the second cake. You can also slide in two loaf tins next to each other.
- In the hot air mode, you can bake simultaneously on several levels.
- For longer cooking times, you can switch off the oven 10 minutes before the end of the cooking time and you can use the residual heat to finish cooking.

Familiarizing yourself with your appliance

You will get to know your new appliance here. We explain the control panel and the individual controls to you. You are informed about the oven interior and accessories.

Oven



1	Door seal
2	Rotisserie spit drive
3	Grill heating element
4	Socket for core temperature probe
5	Socket for additional heating element
	(special acessory for baking stone and roaster)
6	Oven vents
7	Recessed handle

NOTICE


Do not place food directly on oven bottom.

Do not obstruct oven vents.

Displays and controls

These instructions apply to different versions of the appliance. Slight deviations are possible depending on the appliance type.

Operation is identical for all appliance versions.



Control panel	These areas are touch-sensi-
	tive. Touch a symbol to select
	the applicable function.
Display	The display shows current set-
	tings and options, for example.
Rotary selector	With the rotary selector you
	can select the temperature
	and make other settings.
Program selec-	With the program selector,
tor	you can select the heating
	function, the cleaning function
	or the basic settings.
	Display Rotary selector Program selec-

Symbols

Symbol	Function
)	Start
	Stop
II	Pause/end
X	Cancel
С	Delete
✓	Confirm/save settings
<u> </u>	Selection arrow
	Open appliance door
i	Launching additional information

<u>>></u>	Quick heating with status indicator
W	Calling up automatic programs or individual
	recipes
rec •	Recording a menu
1_	Edit settings
> <u>A</u> ¤	Enter a name
×	Delete letters
₼	Child lock
0	Launching the timer menu
(II)	Launching the Sabbath mode
	Demo mode
1	Core temperature probe
1.	Start rotisserie spit
1.	Stop rotisserie spit
>> ,	Start pre-roast stage
>> _	End pre-roast stage
<u></u>	Network connection (Home Connect)

Colors and display

Colors


The various colors serve to guide you in the various adjustment situations.

Orange	First settings
	Main functions
Blue	Basic settings
	Cleaning
White	Adjustable values

Presentation

The presentation of symbols, values or the entire display changes depending on the situation.

Zoom	The display of the setting you are just changing is enlarged.
	Just before it elapses, a duration that is just elapsing is enlarged (e.g. the last 60 seconds in the case of timers).
Minimized display screen	After a short time, the display screen is minimized and only the most important things are displayed. This function is the default and can be modified in the basic settings.



Standby

en-us

The appliance switches to standby mode if no function is set or the childproof lock is activated.

The brightness of the control panel is dimmed in standby mode.

Notes

- Different things can be displayed in standby mode.
 The default setting is the GAGGENAU logo and the time
- The brightness of the display depends on the vertical viewing angle.
- You can change the display and the brightness at any time in the basic settings. → "Basic settings" on page 36

Activate appliance

In order to exit standby mode, you can either

- Set the function selector.
- Touch a control panel,
- or open or close the door.

Now you can set the desired function. Read the appropriate chapters to learn how to set functions.

Notes

- If "Standby screen = off" is selected in the factory setting, you must turn the function selector to exit the standby mode.
- The standby display appears again if you have not made any settings for a long while after activation.
- The cooking compartment lighting goes out after a little while if the door is open.

Automatic door opening

When you touch the symbol, the appliance door springs open and you can open it fully with the handle recess at the side.

Automatic door opening does not work when the child lock is activated or in the event of a power failure. You can open the door manually with the handle recess at the side

Additional information i and i°

By touching the **i** symbol, you can call up additional information. For example, information on the type of heating set or on the current temperature of the cooking compartment.

Note: During continuous operation after heating up, slight deviations in temperature are normal.

The i^{\odot} symbol appears for important information and indicates that an action is required. Important information on safety and operating status is also occasionally displayed automatically. These messages disappear automatically after a few seconds, or must be confirmed with \checkmark .

With Home Connect messages, the Home Connect status additionally appears in the i^{\oplus} . You will find more information about this in the section entitled \longrightarrow "Home Connect" on page 32.

Cooling fan

Your appliance has a cooling fan. The cooling fan switches on during operation. Depending on the appliance version, the warm air escapes above or under the door.


After removing cooked food, keep the door closed until the appliance cools down. The appliance door must not be left ajar, as adjoining kitchen furniture may be damaged. The cooling fan continues to run for a while and then switches off automatically.



CAUTION

Do not cover up the ventilation slots. Otherwise, the appliance will become overheated.

Program selection positions



Position	Function/type of heat- ing	Temperature	Application
0	Off position		
żģ:	Light		Turn on the oven cavity light. Access to other functions, e.g. automatic programs, individual recipes, remote start (Home Connect).
2	* Convection	120 - 550°F (50 - 300°C) Default temperature 340°F (170°C)	Convection: For cakes, cookies and baked casseroles on several levels. The fan in the rear wall of the oven distributes the heat evenly throughout the oven cavity.
3	♣ ^e Economy	120 - 550°F (50 - 300°C) Default temperature 340°F (170°C)	Energy-saving convection mode for cakes, meat, baked casseroles, and gratins. The convenience features (e.g. the oven lighting) remain off. The oven temperature can only be displayed while the oven is heating up. Do not preheat the oven.
			Place the food into the cold, empty oven cavity and start the stated cooking time. Keep the oven door closed during cooking to prevent heat escaping from the oven.
4 120 - 550°F (50 - 300°C) For cakes in p Top + Default temperature roasting. bottom heat 340°F (170°C)	For cakes in pans or sheet cakes, baked casseroles,		
	•	•	rouoting.
5 _ 120 - 550°F (50 - 300°C) For sheet cakes, cookies	For sheet cakes, cookies, cakes with meringue, grill-		
	Top + ⅓ bottom heat	Default temperature 340°F (170°C)	ing, and baked casseroles with gratin. Very well-suited for a situation when the food should be heated from above toward the end of preparation.
6		120 - 550°F (50 - 300°C)	Targeted heat from above, for example grilling cake
	Top heat	Default temperature topped with fruit and meringue. 340°F (170°C)	topped with fruit and meringue.
7	- 	120 - 550°F (50 - 300°C)	For cheesecake, bread in loaf pans, dishes in a water
	⅓ top + bottom heat	Default temperature 340°F (170°C)	bath (e.g. egg custard, crème brûlée). For roasting without a lid and warming up foods (foods dry out less).
			Very well-suited for a situation when the food should be heated from above toward the end of preparation.
8		120 - 550°F (50 - 300°C)	For the final baking stage (such as for moist cakes
	Bottom heat	Default temperature topped with fruit), for preserving, for bath.	topped with fruit), for preserving, for dishes in a water bath.
9	<u>*</u>	120 - 550°F (50 - 300°C)	Additional heat from below for moist cakes, such as
	Convection + bottom heat	Default temperature 340°F (170°C)	cake topped with fruit.

en-us Familiarizing yourself with your appliance

Position	Function/type of heat- ing	Temperature	Application
10	<u>*</u>	120 - 550°F (50 - 300°C)	For high baked casseroles, lasagne, onion tart, egg
	Convection + 1/3 bottom heat	Default temperature 340°F (170°C)	dishes (e.g. tortillas, farmers' omelettes).
11	######################################	120 - 550°F (50 - 300°C)	Even, all-round heating for meat, poultry and whole
	Broil + circulated air	Default temperature 430°F (220°C)	fish.
12	www	120 - 550°F (50 - 300°C)	To grill flat pieces of meat, sausages or fillets of fish.
	Broil	Default temperature 430°F (220°C)	Cooking "au gratin."
13	w	120 - 550°F (50 - 300°C)	Only the center part of the grill heating element is
	Economy broil	Default temperature 430°F (220°C)	heated. Energy-saving grilling for small amounts.
14	ww	120 - 550°F (50 - 300°C) Default temperature 480°F (250°C)	Can only be used with the baking stone and heating
	•		element (optional accessories).
			Baking stone heated from below for crisp stone-baked pizza, bread or rolls.
15		120 - 430°F (50 - 220°C)	Can only be used with the roaster, pull-out system and
		Default temperature 360°F (180°C)	heating element (optional accessories).
			Heatable cast iron roasting pan for large quantities of meat, baked casseroles or holiday roasts.
16	\bigcirc	85 - 120°F (30 - 50°C)	Proofing: For yeast dough and sourdough.
	Dough proofing	Default temperature 100°F (38°C)	Dough will proof considerably more quickly than at room temperature. The optimal temperature setting for yeast dough is 100°F (38 °C).
17	* 0	100 - 140°F (40 - 60°C)	Even, gentle defrosting.
	Defrosting	Default temperature 115°F (45°C)	For vegetables, meat, fish and fruit.
18	<u></u>	85 - 250°F (30 - 120°C)	Keeping food warm, pre-heating crockery.
	Keeping warm	Default temperature 160°F (70°C)	
S	B	· · · · · · · · · · · · · · · · · · ·	The basic settings of your appliance can be adjusted
	Basic settings		individually.
	√+ Pyrolytic cleaning	905°F (485°C)	Self-cleaning

Accessories

Use only the accessories included or obtainable from after-sales service. It has been specially adapted to your appliance. Make sure you always insert accessories into the interior the right way round.

Your appliance comes with the following accessories:




Baking tray, enameled





Wire grill tray







Rotisserie spit



Plug-in core temperature probe

Special accessories

You can order the following accessories from your specialist dealer:

BA 018 165	Pull-out system Fully extendable telescopic pull-out rack and pyrolysis-proof cast frame
BA 028 115	Baking tray, enameled, 31/4" (30 mm) deep
BA 038 165	Wire rack, chrome-plated, with feet
BA 058 115	Heating element for baking stone and roaster
BA 058 133	Baking stone Including heating element and pizza paddle (order heating element separately
BS 020 002	Pizza paddle, set of 2
GN 340 230	GN 2/3 cast aluminum roaster, height 6 1/2" (165 mm), non-stick (Order heating element and pull-out system separately)
The sales are seen	and a contract of the contract of the contract of a second

Use the accessories only as indicated. The manufacturer assumes no liability for incorrect usage of the accessories.

Remove any accessories that are not required during operation from the cooking compartment. Bush for the additional heating element at the back of the cooking compartment: Always leave the cover in during normal operation without the additional heating element.

Before using the appliance for the first time

In this chapter, you can find out what you must do before using your oven to prepare food for the first time. First read the section entitled → "IMPORTANT SAFETY INSTRUCTIONS" on page 4.

The appliance must be completely installed and connected.

After connecting the appliance to the power supply, the "Initial settings "menu will be displayed. Now you can now configure your new appliance for initial set-up.

Notes

• The "Initial settings" menu will appear only after the appliance has been connected to a power supply and switched on for the first time, or if the appliance has not been connected to a power supply for a number of days.

Once the appliance has been connected to a power supply, the GAGGENAU logo will appear first for approximately 30 seconds. The "Initial settings" menu will then appear automatically.

You can change the settings at any time in the basic settings. → "Basic settings" on page 36

Setting the language

The default language appears in the display.

- 1. Select the desired display language with the rotary selector.
- 2. Confirm with .

Setting the time format

the two possible formats 24h and AM/PM appear in the display. The default format is 24h.

- 1. Set the required format with the rotary selector.
- 2. Confirm with \checkmark .

Setting the time

The time appears in the display.

- 1. Set the required time with the rotary selector.
- 2. Confirm with .

Setting the date format

The three possible formats D.M.Y, D/M/Y and M/D/Y appear in the display. The D.M.Y is the default.

- 1. Set the required format with the rotary selector.
- 2. Confirm with .

Setting the date

The default date appears in the display. The day setting is already active.

- 1. Set the required day with the rotary selector.
- 2. Switch to the month setting with the > symbol.
- 3. Set the month with the rotary selector.
- 4. Switch to the year setting with the > symbol.
- 5. Set the year with the rotary selector.
- Confirm with ✓.

Setting the temperature unit

The two possible units °C and °F will appear on the display. The default unit is °C.

- 1. Use the rotary selector to select the unit you require.
- Press ✓ to confirm.

Completing initial set-up

"Initial set-up complete" will appear on the display.

Press ✓ to confirm.

The appliance will switch to standby mode and the standby display will appear. The appliance is now ready to use.

Heating up the oven

Make sure that there is no leftover packaging in the cooking compartment.

To eliminate the new-appliance smell, heat up the oven with it empty and the door closed. One hour with hot air * at 200 °C is ideal for this.


Cleaning accessories

Before using accessories for the first time, thoroughly clean them with hot soapy water and a soft dish cloth.

Operating the appliance

Oven interior

The cooking compartment has five shelf levels.



$\overline{\mathbf{\Lambda}}$

CAUTION

Do not place anything on the cooking compartment floor. Do not cover it with aluminium foil. A build-up of heat could damage the appliance or cause injury.



A CAUTION

Do not slide any accessories between the shelf positions, or they may tip.



WARNING

Risk of burns!


The inside of the appliance door becomes very hot during operation. Always open the appliance door as far as it will go. Ensure that the appliance door does not swing back. Avoid contact with the inside of the appliance door.

Inserting the rack

The accessories feature a rack stop function. The rack stop function prevents tilting of accessories when pulling them out. You must insert accessories in the oven interior correctly so that tilt protection will work.

Inserting the rack

 Tilt the rack to guide the rack stop in between the rails of the rack holders . The rack stop has to face downwards. 2. Lower the rack and slide it into the oven, so that the rack stop can engage **B**. Make sure the rack's safety rod is at the rear and top C.



Turning on

- 1. Set the required heating mode using the function selector. The chosen heating mode and the default temperature are displayed.
- 2. If you want to change the default temperature: set the required temperature with the rotary selector.

The preheating symbol <u>>></u> appears on the display. The bar continuously shows the preheating status. When the set temperature is reached, a signal sounds and the preheating symbol <u>»</u> goes off.

Note: The oven interior lighting stays switched off at a temperature setting below 160° F (70°C).

Switching off:

Turn the function selector to 0.

Quick heat

With the "Quick heat" function, your appliance reaches the desired temperature particularly quickly in the top heat, bottom heat, and top/bottom heat types of heating.

To ensure an even cooking result, do not place your food in the cooking compartment until "Quick heat" is complete and the <u>>></u> heat-up symbol goes out.

Note: The "Quick heat" function is preset in the factory settings. In the basic settings, you can select <u>>></u> Quick heat or <u>↑</u> Heat-up. → "Basic settings" on page 36

Safety shut-off

For your protection, the appliance has a safety shut-off feature. Every heating operation is switched off after 12 hours if the appliance is not operated during this time. A message appears in the display.

Exception:

programming with the long-term timer.

Turn the program selection to 0, after which you can operate the appliance in the manner to which you are accustomed.

Timer functions

In the timer menu, set:

- ∑ Timer
- Stopwatch
- Cooking time (not in the idle state)
- Q Cooking time end (not in the idle state)

Launching the timer menu

You can launch the timer menu from any mode. Only from the factory settings, program selection is set to **S**, the time menu is not available.

Touch the O symbol.



The timer menu appears.

Timer

The timer runs independently of the other appliance functions. You can enter a maximum of 90 minutes.


Setting the timer

- Call up the Timer menu.
 The "Timer" function ∑ is displayed.
- 2. Turn the rotary selector to set the desired time.



3. Start with ▶.

The Timer menu closes and the timer starts to run. The symbol for the timer Σ appears on the display and the time can be seen counting down.



A signal sounds once the time has elapsed. The audible signal ceases if you touch the \checkmark symbol.

You can exit the Timer menu at any time by touching the **X** symbol. This way, the settings are lost.

Suspend timer:

Call up the Timer menu. Select the "Timer" function with \searrow , select \boxtimes , and touch the \blacksquare symbol. To let the timer run on, touch the \triangleright symbol.

Switch off the timer early:

Call up the Timer menu. Select the "Timer" function with \searrow , select \boxtimes , and touch the \subset symbol.

Stopwatch

The stopwatch runs independently of the other appliance functions.

The stopwatch counts up from 0 seconds to 90 minutes.

It has a pause function. Therefore, you can stop the timer in between times.


Starting the stopwatch

- 1. Launch the timer menu.
- 2. With **>**, select the "Stopwatch" function ♂.




3. Start with ▶.

The timer menu is closed and the time runs. The $\overline{\diamondsuit}$ symbol and the elapsing timer are shown in the display.



Stopping and restarting the stopwatch

- 1. Launch the timer menu.
- 2. With **>**, select the "Stopwatch" function **♦**.
- 3. Touch the **II** symbol.



The time stops. The symbol changes to Start ▶ again.

4. Start with ▶.

The time continues to run. Once 90 minutes have been reached, the display pulsates and a signal sounds. It goes off when you touch the 🗸 symbol. The 🕭 symbol disappears from the display. The operation has ended.

Switching off the stopwatch:

Launch the timer menu. With >, select the "Stopwatch" function \bullet and touch the \bullet symbol.

Cooking time

If you set a cooking time for your meal, the appliance switches off heating automatically after this time has elapsed.

You can set a cooking time from 1 minute to 23:59 hours.

Setting the cooking time


You have set the heating function and temperature and you have placed your dish in the oven interior.

- 1. Touch the \bigcirc symbol.
- 2. With >, select the "Cooking time" function .
- 3. Set the required cooking time with the rotary selector.




Start with .

The appliance starts. The timer menu is closed. The temperature, the operating mode, the remaining cooking time and the end of the cooking time appear in the display.



One minute before expiration of the cooking time, the expiring cooking time is enlarged in the display.



The appliance switches off after expiration of the cooking time. The nulsates and a signal sounds. It goes off prematurely if you touch the \checkmark symbol, open the appliance door or set the program selection to 0.

Interrupting the cooking time:

Launch the timer menu. With >, select the "Cooking time" function . With II interrupt the cooking time. With ▶ continue the cooking time.

Changing the cooking time:

Launch the timer menu. With , select the "Cooking" time" function . Set the cooking time with the rotary selector. Start with .

Clearing the cooking time:

Launch the timer menu. With >, select the "Cooking time" function **()**. Clear the cooking time with **C**. Return to normal operation with X.

Canceling the entire operation:

Set the program selection to 0.

Note: You can also change the heating function and temperature during the cooking time.

End of cooking time

You can defer the end of the cooking time until later.

Example: it is 2 pm. The meal takes 40 minutes to cook. It should be ready by 3.30 pm.

Enter the cooking time and shift the end of the cooking time to 3.30 pm. The electronic circuitry calculates the starting time. The appliance starts automatically at 2:50 pm and switches off at 3.30 pm.

Note that easily perishable foodstuffs must not be left in the oven for too long.

Shifting the end of the cooking time

You have set the heating function, the temperature and the cooking time.

- 1. Touch the O symbol.
- 2. With >, select the "End of cooking time" function Q.



- Set the required cooking time end with the rotary selector.
- 4. Start with ▶.



The appliance assumes a waiting mode. The operating mode, the temperature, the cooking time and the end of the cooking time appear in the display. The appliance starts at the calculated time and switches off automatically when the cooking time has elapsed.

Note: If the **()** symbol flashes: you have not set a cooking time. Always set a cooking time first.

The appliance switches off after expiration of the cooking time. The \bigcirc pulsates and a signal sounds. It goes off prematurely if you touch the \checkmark symbol, open the appliance door or set the program selection to $\mathbf{0}$.

Changing the cooking time end:

Launch the timer menu. With \searrow , select "End of cooking time" \bigcirc . Set the required cooking time end with the rotary selector. Start with \triangleright .

Canceling the entire operation:

Set the program selection to 0.

Sabbath mode and Yom Tov mode

Sabbath mode

With this function, the appliance maintains a temperature between 120 and 450°F (50 and 230°C) with the convection heating function.

You can keep dishes warm for up to 74 hours without having to switch on or off.

Note that easily perishable foodstuffs must not be left in the oven for too long.

Note: You must activate the Sabbath mode in the factory setting in order to operate the mode. → "Basic settings" on page 36

Follow these steps:

- 1. Set the program selector to S.
- 2. Select "Factory setting" with the rotary selector.
- Confirm by touching the symbol.
- 4. Rotate the selector to Sabbath mode 3.
- Confirm by touching the symbol.
- 6. Rotate the selector to "activate".
- 7. Corfirm by touching the \checkmark symbol.
- 8. Turn the oven off.

Setting the Sabbath mode

- 1. Set the program selector to 🖔.
- 2. Touch the (symbol.


The suggested value of 24h at 185° F (85°C) appears in the display. Start with

Change the cooking time and the temperature.



- Changing the cooking time (): Touch the O symbol. Set the preferred cooking time with the rotary selector. You can set up to 74 hours. Confirm by touching the \checkmark symbol. Then changing the temperature becomes an option.
- 4. Changing the temperature: Set the required temperature with the rotary selector.
- 5. Start with ▶.

The appliance starts. (1) and the temperature appear in the display. The Sabbath screen will appear as shown.



The oven and display lighting is off. The control panel is blocked and no tone can be heard when you touch it.

The appliance no longer heats after expiry of the time. The display is blank. Set the program selector to 0.

Switching off:

To cancel the operation, set the program selector to 0.

Yom Tov mode

With this function, the appliance is programmed to perform in three stages.

Stage 1 and 2 can be programmed for a maximum total duration of 74 hours. The duration of Step 3 is 1 hour and cannot be modified.

Stage 1: maintains a warm temperature of 122° F (50°C) in the convection heating function. The interior oven lights remain off through this stage.

Stage 2: the appliance raises to a desired temperature setting and maintains a temperature between 120 and 450° F (50 -230°C). For warming and cooking foods in the convection heating function. The desired time can be adjusted for this stage. The interior oven lights will be on during this time.


Stage 3: maintains a warm temperature of 122° F (50°C) in the convection heating function for 1 hour after stage 2 has ended. The interior oven lights will be on during this time.

Note that easily perishable foodstuffs must not be left in the oven for too long.

Setting the Yom Tov mode

- 1. Set the program selector to 点.
- 2. Touch the 🕦 symbol.

The suggested value of 24h at 185° F (85°C) appears in the display.




To set Stage 2 cooking time with rotary selector:

- 1. Touch the ① symbol to adjust the duration of Stage 2 cooking time ①.
- Set the desired Stage 2 cooking time with the rotary selector.
- Touch the > symbol to adjust the end of Stage 2 cooking time Q.
- 4. Select the end time with the rotary selector.
- 5. Change the date if needed by touching the > symbol to 31.
- 6. Rotate the selector to the desired date.
- 7. Confirm settings by touching the \checkmark symbol.

To set Stage 2 temperature:

- 1. Rotate selector to desired Stage 2 temperature.
- Start with ▶.

The temperatures of Stage 1 and Stage 2 appear in the display. The remaining time to the beginning of Stage 2 is counted down in the display. The Yom Tov screen will appear as shown.



The program will begin with the pre-set warm temperature without light, then advance to the programmed temperature with light until the end of the set date and time, and then maintain the pre-set warm temperature for 60 minutes.

The appliance no longer heats after expiry of the time. The display is blank. Set the program selector to **0**.

Switching off:

To cancel the operation, set the program selector to 0.

Automatic programs

You can prepare a wide range of food using the automatic programs. The appliance will choose the optimal setting for you.

To achieve good results, the cooking compartment must not be too hot for the type of food you have selected. If it is, a message will appear on the display. Allow the appliance to cool and then try again.

Information on the settings

- The cooking result depends on the quality of the food and the size and type of cookware. For an optimal cooking result, only use food that is in good condition and meat that is chilled to refrigerator temperature. For frozen food, use food straight out of the freezer only.
- The automatic program suggests a temperature, type of heating and cooking time.
- For some dishes, you will be required to enter the weight. It is not possible to set weights outside of the intended weight range.
- For some dishes, you will be asked to enter desired level of browning, the thickness of the food and/or the cooking level of the meat or vegetables.
- For some dishes, the cooking compartment is preheated empty. Place the food in the cooking compartment once the preheating is complete and a message appears in the display.
- Your preferred settings will be shown next time as a suggestion.

Core temperature probe

For some recipes, you will need the core temperature probe. Use the core temperature probe for these recipes.

→ "Core temperature probe" on page 26

Selecting a dish

The following categories are available. One or more dishes are listed beside each category.

Categories:

- Vegetables
- Oven dishes
- Fish
- Meat and poultry
- Bread, pizza and cake
- Drying

Dough

Applying settings for dishes

You are guided through the entire setting process. Follow the instructions in the display.

Use the rotary selector to scroll through the individual levels.

- 1. Set the function selector to \$\circ\$.
- 2. Touch the **Ψ** symbol. Press **✓** to confirm.
- 3. Use the rotary selector to select the category and press \checkmark to confirm.
- 4. Use the rotary selector to select the required dish and press 🗸 to confirm.

The possible settings appear in the display. For many dishes, you can change the settings to suit your

For some dishes, you must set the weight.

information about accessories and preparation methods.

5. Press V to confirm the required settings. Follow the directions on the display.

The cooking time will count down on the display.

Once the cooking time has elapsed, an audible signal sounds. The appliance stops heating.



WARNING

Risk of scalding!

Hot steam can escape when you open the appliance door. Open the appliance door with caution. Keep children away.

Opening the appliance door affects the cooking result. Open the appliance door only briefly. The automatic program is interrupted and continues to run after closing the appliance door.

Adding extra cooking time

After the cooking time has ended, you can leave some dishes to continue cooking if you are not satisfied with the cooking result.

A query appears on the display, which asks if you want to continue cooking.

- Press ✓ to confirm.
- 2. Select a single or double cooking time, depending on requirements.
- 3. Press ▶ to start.
- 4. If the "Continue cooking" function has ended, turn the function selector to 0.

Changing and canceling

After starting the appliance, the settings can no longer be changed.

If you want to cancel the operation, turn the function selector to 0.

Calling up the last automatic programs used

The last five dishes with the selected settings are saved. You have the option of saving these dishes with the selected settings as individual recipes. You can no longer change the settings of an individual recipe if you have saved it using the "Last automatic programs" function→ "Personal recipes" on page 24

- 1. Set the function selector to 次.
 - is displayed.
- 2. Touch the wsymbol.
- 3. Use the rotary selector to select "Last automatic programs" and press 🗸 to confirm.
- 4. Use the rotary selector to select the required dish and press ✓ to confirm.
- 5. Enter a name for the dish and save. → "Entering a name" on page 25

Personal recipes

You can save up to 50 individual recipes. You can record a recipe. You can assign these recipes a name so that you can fall back on them quickly and conveniently if you need them.

Recording a recipe

It is possible to set up to 5 phases consecutively while recording at the same time.

- 1. Set the function selector to 🔅.
- 2. Touch the W symbol.
- 3. Use the rotary selector to select "Individual recipes" and press ✓ to confirm.
- 4. Use the rotary selector to select a free memory location.
- Touch the ^{rec}
 symbol.



- 6. Set the desired temperature with the rotary selector.
- 7. The cooking time is recorded.
- 8. Recording another phase:

Set the program selection to the required heating function. Set the required temperature with the rotary selector. A new phase begins.

- Once the appliance has achieved the desired cooking result, touch the symbol to end the recipe.
- 10. Enter the name under "ABC". → "Entering a name" on page 25

Notes

- Recording a phase does not begin until the appliance has reached the set temperature.
- Every phase must last at least one minute.
- During the first minute you can change the heating function or the temperature.

Enter the core temperature for a phase:


Insert the core temperature probe in the socket in the oven interior. Set the heating function and temperature. Touch the \nearrow symbol. With the rotary selector, enter the required temperature and confirm it with \nearrow .

Programming a recipe

You have the option of programming and saving up to five phases of preparation.

- 1. Set the function selector to 🔅.
- 2. Touch the W symbol.
- 3. Use the rotary selector to select "Individual recipes" and press ✓ to confirm.
- 4. Choose a free storage location with the rotary selector.
- 5. Touch the _ symbol.
- 6. Enter the name under "ABC". → "Entering a name" on page 25
- 7. Choose the first phase with the > symbol.

The heating function and temperature set at the start are displayed. You can change the heating function and temperature with the rotary selectors.



- 8. Choose the time setting with the > symbol.
- 9. Set the required cooking time with the rotary selector.
- 10. Choose the next phase with the > symbol.
 - or -

Preparation is complete, end input.

- 11. Save with \checkmark .
 - or -

Cancel with X and quit the menu.


Enter the core temperature for a phase:

Choose the next phase with the > symbol. Set the heating function and temperature. Touch the \(\simeq \) symbol. With the rotary selector, enter the required temperature and confirm it with \(\simeq \).

Note: For phases for which a core temerature has been programmed you cannot set a cook time.

Entering a name

1. Enter the recipe's name under "ABC".



Rotary	Selecting letters		
selector	A new word always beings with an		
	upper case letter.		
> <u>A</u> [⊼]	Press briefly: cursor to the right		
	Press long: switch to diacritics and special characters		
	Press twice: insert line space		
<u>Ä</u>	Press briefly: cursor to the right		
	Press long: switch to normal characters		
	Press twice: insert line space		
×	Clear letters		

- 2. Save with .
 - or -

Cancel with **X** and quit the menu...


Note: For entering a name, Latin characters, certain special characters and numbers are available.

Starting a recipe

- 1. Set the function selector to 🔅.
- 2. Touch the W symbol.
- 3. Use the rotary selector to select "Individual recipes" and press \checkmark to confirm.
- 4. Use the rotary selector to select the desired recipe.
- 5. Press ▶ to start.

The operation begins. The cooking time starts counting down.

The settings for each phase are shown in the display.



Notes

- The cooking time does not start counting down until the appliance has reached the set temperature.
- You can use the rotary selector to change the temperature while the recipe is in progress. This does not change the saved recipe.

Change recipe

You can change the settings of a recorded or programmed recipe.

- 1. Set the function selector to 🔅.
- 2. Touch the W symbol.
- 3. Use the rotary selector to select "Individual recipes" and press \checkmark to confirm.
- 4. Use the rotary selector to select the desired recipe.
- 5. Touch the _ symbol.
- 6. Use the > symbol to select the desired phase. The programmed heating type, temperature, and cooking time are displayed. You can change the settings with the rotary selector or the function
- selector. Save with ✓.
 - or -

Cancel with X and exit the menu.

Deleting a recipe

- 1. Set the function selector to any type of heating.
 - The waymbol is displayed.
- 3. Use the rotary selector to select the desired recipe.
- 4. Delete the recipe with C.
- 5. Confirm with \checkmark .

Core temperature probe

The core temperature probe makes it possible to cook with exact precision. It measures the temperature inside the food being cooked. When the required core temperature has been reached, the probe switches off automatically, ensuring that all food is cooked perfectly.



WARNING

Risk of electric shock!

Use of a wrong core temperature probe can damage the insulation. Use only the core temperature probe intended for this appliance.



WARNING

Risk of burns!

The oven interior and the core temperature probe become very hot. Use oven mitts to plug and unplug the core temperature probe.



CAUTION

Damage to the core temperature probe:

Do not use the core temperature probe with the heating modes "Broil" or "Economy Broil". Before using the heating modes "Broil" or "Economy Broil", remove the core temperature probe from the oven cavity. It is possible to use the heating mode "Broil + Circulated Air" at temperatures up to 480° F (250 °C).



CAUTION

Damage to the core temperature probe:

The core temperature probe may be damaged at temperatures above 480° F (250 °C). When using the core temperature probe, never set the temperature above 480° F (250 °C).

Only use the core temperature probe supplied. You can purchase it as a spare part from Customer Service or from the online shop.

When using the core temperature probe, never place the food on the top shelf position in the oven.

After use, always remove the core temperature probe from the oven cavity. Never store it inside the oven cavity.

After each use, clean the core temperature probe with a damp cloth. Do not clean in the dishwasher.


Inserting the core temperature probe into the food

Insert the core temperature probe into the food before you place the food in the oven cavity.

The core temperature probe has three measuring points. Insert the core temperature probe as far as possible. Th core temperature probe must not be inserted in the fat or be touching the ovenware or bones.


Meat: Insert the core temperature probe at an angle from above as far as it will go into the meat.

For more than one piece of meat, insert the core temperature probe into the middle of the thickest piece.




Poultry: Insert the core temperature probe as far as it will go into the thickest point in the breast. Depending on its structure, insert the core temperature probe into the poultry crossways or lengthways. With poultry, make sure that the tip of the core temperature probe does not protrude into the cavity in the middle of the bird.





Fish: Insert the core temperature probe behind the head as far as it will go towards the spine. Place the whole fish onto the wire rack and prop it up in the swimming position using half a potato.



Turning the food: If you want to turn the food, do not remove the core temperature probe. Once you have turned the food, check that the core temperature probe is correctly positioned in the food.

If you remove the core temperature probe during operation of the appliance, all settings are reset and you have to apply them again.

Setting the core temperature

CAUTION

Damage to the core temperature probe:

The core temperature probe may be damaged if the distance between the grill heating element and the core temperature probe is too small. Make sure that the distance between the grill heating element and the core temperature probe or the cable of the core temperature probe is a few centimeters. The meat may expand during the cooking process.



CAUTION

Damage to the core temperature probe:

Do not trap the cable of the core temperature probe in the appliance door.

- 1. Insert the food to cook in the oven cavity with a core temperature probe inserted. Insert the core temperature probe into the socket in the oven cavity and close the appliance door.
- 2. Turn the function selector to the desired heating type.
- 3. Use the rotary selector to set the oven cavity temperature.

- 4. Touch the \(\sigma \) symbol. Use the rotary selector to change the set core temperature for the food and confirm with \nearrow .
 - The core temperature set must be higher than the current core temperature.
- 5. The appliance heats with the set heating type.
 - The display indicates the current temperature, and below that the set core temperature.

You can change the set core temperature at any time.

Once the set core temperature is reached, a signal sounds. Cooking is automatically ended. Confirm with 🗸 and turn the function selector to 0.

Estimated cooking time

After preheating, if the appliance has a temperature setting above 212° F (100 °C), when the core temperature probe is inserted, the display shows an estimated cooking time approx. 5-20 minutes into the cooking time.

The estimated cooking time is continually updated. The longer the cooking process lasts, the more precise the estimated cooking time becomes. Do not open the appliance door; this distorts the estimated cooking time.

The estimated cooking time is displayed in normal operation and in the automatic program.

The current core temperature is shown in the display when you touch the i symbol.

The estimated cooking time display can be deactivated in the basic settings so that the current core temperature is shown instead.→ "Basic settings" on page 36

Notes

- At the beginning of the cooking time, "<59° F" ("<15°C") is displayed for 3-4 minutes for the current core temperature.
- The measurable range is 59 to 210° F (15°C to 99°C). Outside the measurable range, <59°F or --°F ("<15°C" or "--°C") is displayed as the current core temperature.
- If you leave the food in the cooking compartment for some time after cooking, the core temperature will continue to rise somewhat due to the residual heat in the cooking compartment.
- If you set programs with the core temperature probe and the cooking timer at the same time, the appliance switches off whichever program reaches the entered value first.

Changing the set core temperature

Deleting the set core temperature

Core temperature guidelines

Use chilled food only, not frozen food. The details given in the table are guidelines. Results depend on the quality and composition of the food.

For hygiene reasons, critical foodstuffs such as fish and game should reach a core temperature of $143 - 158^{\circ}$ F (62 - 70 °C); for poultry and minced meat this should be as high as $176 - 185^{\circ}$ F (80 - 85° C).

Food	Core temperature		
	guideline		
Beef			
Sirloin, tenderloin, entrecôte			
very rare	113 - 117°F		
	(45 - 47 °C)		
rare	122 - 126°F		
	(50 - 52 °C)		
medium	137 - 140°F		
	(58 - 60 °C)		
well-done	158 - 167°F		
	(70 - 75 °C)		
Roast beef	176 - 185°F		
	(80 - 85 °C)		
Pork			
Pork roast	162 - 176°F		
	(72 - 80 °C)		
Pork loin			
medium	149 - 158°F		
	(65 - 70 °C)		
well-done	167°F (75 °C)		
Meat loaf	185°F (85 °C)		
Fillet of pork	149 - 158°F		
	(65 - 70 °C)		
Veal			
Veal roast, well-done	167 - 176°F		
	(75 - 80 °C)		
Breast of veal, stuffed	167 - 176°F		
	(75 - 80 °C)		
Saddle of veal			
	-		

Food	Core temperature
	guideline
medium	137 - 140°F
	(58 - 60 °C)
well-done	149 - 158°F
	(65 - 70 °C)
Fillet of veal	
rare	122 - 126°F
	(50 - 52 °C)
medium	137 - 140°F
	(58 - 60 °C)
well-done	158 - 167°F
	(70 - 75 °C)
Game	
Saddle of venison	140 - 157°F
	(60 - 70 °C)
Leg of venison	158 - 167°F
	(70 - 75 °C)
Venison loin steaks	149 - 158°F
	(65 - 70 °C)
Saddle of hare or rabbit	149 - 158°F
	(65 - 70 °C)
Poultry	
Chicken	195°F (90 °C)
Guinea fowl	175 - 185°F
	(80 - 85 °C)
Goose, turkey, duck	185 - 195°F
	(85 - 90 °C)
Duck breast	
medium	131 - 140°F
	(55 - 60 °C)
well-done	158 - 176°F
	(70 - 80 °C)
Ostrich steak	140 - 149°F
	(60 - 65 °C)
Lamb	,
Leg of lamb	
medium	140 - 149°F
	(60 - 65 °C)
well-done	158 - 176°F
well-dolle	(70 - 80 °C)
Saddle of lamb	(70-00-0)
	101 1400
medium	131 - 140°F (55 - 60°C)
	(55 - 60 C)
well-done	149 - 167°F
	(65 - 75 °C)
Mutton	
Leg of mutton	

Food	Core temperature guideline
medium	158 - 167°F (70 - 75 °C)
well-done	176 - 185°F (80 - 85°C)
Saddle of mutton	
medium	158 - 167°F (70 - 75°C)
well-done	176 °F (80 °C)
Fish	
Fillet	144 - 149°F (62 - 65 °C)
Whole	149°F (65 °C)
Terrine	144 - 149°F (62 - 65 °C)
Other provisions	
Bread	205°F (96 °C)
Paté	162 - 167°F (72 - 75 °C)
Terrine	140 - 158°F (60 - 70 °C)
Foie gras	113°F (45 °C)
Reheating food	167°F (75°C)

Rotisserie spit

Using the rotisserie spit, you can prepare large roasts such as rolled roast and poultry particularly well. The meat becomes crispy and brown all round.

You can use the rotisserie spit in all modes of operation. You achieve the best results with the "Broil" or "Top heat" heating functions.


$\overline{\Lambda}$

CAUTION

Do not use the temperature probe in combination with the rotisserie spit.

Preparation


- 1. Insert both supports in the sockets on the grill tray. The drive is on the left.
- 2. Plug the right retaining clip onto the rotisserie spit and screw it in firmly.
- 3. Place the food you want to cook on the rotisserie spit's center. Secure protruding parts (e.g. wings) to make sure they do not touch the grill heating element.




4. Plug the left retaining clip onto the rotisserie spit and screw it in firmly.

en-us Rotisserie spit

5. Place the rotisserie spit on the supports. Latch the square shaft into the drive section.



 Insert the rotisserie spit in the lowest insertion level in the oven. The drive spindle must engage in the opening on the oven's rear wall.



Switching on the rotisserie spit

- 1. Set the required temperature and heating function.
- Touch the symbol. The rotisserie spit is switched on.



Switching off the rotisserie spit

- 1. Touch the 🖍 symbol. The rotisserie spit's drive stops.
- 2. Switch off the oven with the program selection.
- 3. Take out the grill tray with the rotisserie spit and place them on a stable, heat-resistant surface.



WARNING

Risk of burns!

Use a glove to remove them.

4. Screw on the handle at the side to remove the rotisserie spit.

Notes

- Use the rotisserie spit at oven temperatures up to 480° F (250°C) only.
- Do not clean the drive part of the rotisserie spit in a dishwasher.

Roasting function

Only with heating mode "Roaster function": You will need the roaster, pull-out system and heating element (optional accessories).

In the searing stage, the oven heats at full power for approx. 3 minutes. This way, you can sear steaks, for example.

Touch the , symbol. The searing stage starts up. You can also set the searing feature several times one after another.



Childproof lock

The appliance has a panel lock to make sure children cannot operate it inadvertently.

Notes


- You must set the child lock in the factory setting to "Available"→ "Basic settings" on page 36
- If there is a power cut while the child lock is activated, it may be deactivated when the power returns.

Activating the child lock

Requirement:

Program selector is set to 0.

Touch the ⊕ symbol for at least 6 seconds.



The child lock is activated. The standby screen appears. The figure at the top of the display.

Deactivating the child lock

Requirement:

Program selector is set to 0.

Touch the \mathbf{Z} symbol for at least 6 seconds.



The child lock is deactivated. You can switch on the appliance in the usual manner.

Home Connect

This appliance can be networked and also controlled remotely using a mobile device. The Home Connect app offers extra functions that complement the networked appliance perfectly. If the appliance is not connected to your home network, it can be operated as usual via the display.

The availability of the Home Connect function depends on the availability of Home Connect services in your country. Home Connect services are not available in every country. You can find more information on this at www.home-connect.com.

Notes

- Ensure that you follow the safety instructions in this
 instruction manual and that you comply with these
 even when you are away from home and are operating
 the appliance via the Home Connect app. You must
 also follow the instructions in the Home Connect app.
- Operating the appliance directly from the appliance always takes priority. It is not possible to operate the appliance using the Home Connect app during this time.
- Refer to the Home Connect documents supplied for more information.

Setting Up

To configure settings via Home Connect, you will need to have installed the Home Connect app on a mobile device.

Your appliance will also need to be connected to your home network and to the Home Connect app. You can choose between the following connection types:

- Connection via LAN cable: The appliance is connected to the home network automatically following confirmation on the appliance.
- Connection via Wi-Fi: Establish the connection to your home network and then the connection to the Home Connect app.

Note: The app will guide you through the entire registration process. In case of doubt, follow the instructions in the app.

Installing the app

Install the Home Connect app on your mobile device (e.g. tablet PC or smartphone).

- 1. On your mobile device, go to the App Store (Apple devices) or the Google Play Store (Android devices).
- 2. Enter the search term "Home Connect".

- Select the Home Connect app and install it on your mobile device.
- 4. Launch the app and set up Home Connect access.

The app will guide you through the registration process.

Connecting the appliance to your home network (LAN)

The appliance must be connected to your home network using a LAN cable.

The network connection will be established automatically when the appliance is connected to the mains electricity supply for the first time and put into operation.

Connecting the appliance to your home network (Wi-Fi with WPS)

Requirements:

- Your router must have a WPS button. You will find information about this in the manual for your router.
- You need to be able to access your router.
- 1. In the basic settings, select @ "Home Connect".
- 2. Touch the _ symbol.
- 3. Turn the rotary selector to "Wi-Fi".
- Confirm by touching the

 ✓ symbol.

A message about the WPS function will appear.

- 5. Touch the \checkmark symbol to continue.
- 6. Turn the rotary selector to "Automatic (WPS)".
- 7. Touch the \checkmark symbol to start the connection process.
- 8. Press the WPS button on the router within the next 2 minutes.

If the display shows "Network connection successful", the connection process is complete. Follow the instructions in the app.

Connecting the appliance to your home network (Wi-Fi without WPS)

- 1. In the basic settings, select @ "Home Connect".
- 2. Touch the _ symbol.
- 3. Turn the rotary selector to "Wi-Fi".
- Confirm by touching the

 ✓ symbol.

A message about the WPS function will appear.

- 5. Touch the **v** symbol to continue.
- 6. Turn the rotary selector to "Manual".
- Touch the symbol to start the connection process.
 The appliance will set up its own "Home Connect" Wi-Fi network to which the tablet or smartphone must be connected.
- 8. Follow the instructions in the app.

If the display shows "Network connection successful", the connection process is complete. Follow the instructions in the app.

Connecting the appliance to the app

Connect your appliance to the app when setting up Home Connect or connect your appliance to an additional Home Connect account. The Home Connect app can be installed on any number of mobile devices, which can then be connected to the appliance.

Requirements:

- The appliance is connected to your home network.
- The Home Connect app has been installed on the mobile device.
- To connect an additional account, select "Home Connect" in the basic settings.
- 2. Use the rotary selector to select "Connect to app".
- 3. Touch the _ symbol and start the connection process with ✓.
- 4. Follow the instructions in the app.

If the display shows "Connection to app successful", the connection process is complete.

Remote Start

Remote start must be activated in order to start and operate your appliance via the Home Connect app. If remote start is deactivated, only the appliance operating modes can be displayed in the Home Connect app and appliance settings can be implemented.

The remote start is automatically deactivated if the appliance door is opened.

When you start the oven using a type of heating on the appliance itself, remote start is activated automatically. You can now make changes or start a new program from your mobile device.

Activating remote start

- 1. Set the function selector to 🔅.
- 2. Touch the 🔊 symbol.

appears next to the **i** symbol.

Remote start is now activated. You can now use the mobile end device to start a type of heating via the app and transfer the required settings to the appliance.

To deactivate the remote start: Touch the 🐔 symbol.

Home Connect settings

Home Connect can be adapted to your specific needs at any time.

Note: You will find the Home Connect settings in the basic settings for your appliance. Which settings the display shows will depend on whether Home Connect has been set up and whether the appliance is connected to your home network.

	Basic setting	Possible settings	Explanation
LAN / WLAN	Connection type	LAN/Wi-Fi	You can switch between connection types (LAN cable and Wi-Fi).
			Follow the instructions for setting up the relevant connection type. "Setting Up" on page 32
	Connecting	Connect/disconnect	Switch the network connection on or off as required (e.g. for holiday).
			Network information is retained after the appliance is switched off. After switching on the appliance, you will need to wait for a few seconds while it reconnects to the network.
			In networked standby mode, the appliance requires max. 2 W.
157	Connect to app		Start the connection process between the app and the appliance.
\bigcap	Software update		As soon as a new software version is available, a message appears in the display. You can install the new software in the Home Connect menu \mathbb{Q} .

	Remote control	Activate/deactivate	Access the appliance's functions via the Home Connect app.
_			When deactivated, only the appliance's operating statuses will be displayed in the app.
\otimes	Delete network set- tings		All network settings can be deleted from the appliance at any time.
	Appliance information		The display shows: MAC address COM module Serial number of the appliance Software version
			You can view more information – such as the SSID (network name), although this depends on the connection type – by touching the arrow button.

Remote Diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance

Note: For further information and details about the availability of Remote Diagnostics in your country, please visit the Service/Support section of your local website: www.home-connect.com

Information on Data Protection

When your appliance is connected to a WLAN network that is connected to the Internet for the first time, your appliance transmits the following categories of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the installed Wi-Fi communication module).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous resetting to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use these Home Connect functions for the first time.

Note: Ensure that the Home Connect functions can be used only in conjunction with the Home Connect app. Information on data protection can be accessed in the Home Connect app.

Declaration of Conformity

Gaggenau Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality meets the basic requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at www.gaggenau.com among the additional documents on the product page for your appliance.



2.4 GHz band: max. 100 mW 5 GHz band: max. 100 mW



BE	BG	CZ	DK	DE	EE	ΙE	EL	
ES	FR	HR	IT	CY	LV	LT	LU	
HU	MT	NL	ΑT	PL	PT	RO	SI	
SK	FI	SE	UK	NO	СН	TR		

5 GHz WLAN (Wi-Fi): For indoor use only

Wi-Fi® Module

FCC/IC Statements

Model: COM2

FCC ID: 2AHES-COM2 IC: 21152-COM2

The Home Connect module is a communication device designed to provide communication between appliances and smart devices.

This module is integrated at the factory, under direct control of BSH Home Appliances Corporation, and is not user servicable or upgradable. At least $7^7/_8$ inch (20 cm) separation distance should be maintained from device to user.

FCC COMPLIANCE STATEMENT

A

CAUTION

Changes or modifications not expressly approved could void your authority to use this equipment.

This device complies with Part 15 of the FCC Rules. Operation to the following two conditions:

- 1. This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

INDUSTRY CANADA STATEMENT

This device complies with Industry Canada licenseexempt RSS standard(s).

Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- This device must accept any interference, including interference that may cause undesired operation of the device.

Operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to cochannel mobile satellite systems.

Basic settings

In the general settings, you can adapt your appliance individually.

- 1. Set the program selector to S.
- 2. Select "General setting" with the rotary selector.
- Touch the ✓ symbol.
- 4. Set the required general setting with the rotary selector.

- 5. Touch the _ symbol.
- 6. Set the general setting with the rotary selector.
- 7. Save with ✓ or cancel with X and quit the current general setting.
- 8. Turn the program selector to **0** to quit the general setting menu.

Changes are saved.

	Basic setting	Possible settings	Explanation
=	Brightness	Stages 1, 2, 3, 4, 5*, 6, 7, 8	Setting display brightness
	Standby screen	On*/Off	Appearance of the standby screen.
G		- Clock	Off: no display. Use this setting to reduce the
		- Clock + GAGGENAU logo*	standby consumption of your appliance.
		- Date	On: several displays can be set, confirm "On" with ✓ and choose the desired display with
		- Date + GAGGENAU logo	the rotary selector.
		- Clock + date	The selection is displayed.
		- Clock + date + GAGGENAU logo	
	Display screen	Minimized*/Standard	When 'Minimized' is set, only the most important details are displayed after a short time.
	Touchpad color	Gray*/White	Select the color of symbols on the touchpads
	Touchpad tone	Tone 1*/Tone 2/Off	Select the signal tone when touching a touch- pad
	Touchpad volume	Levels 1, 2, 3, 4, 5*, 6, 7, 8	Sets the volume of the touchpad tone
>>	Quick heat	On*/off	With quick heat, the required temperature is reached particularly quickly.
	Preheating signal	On*/Off	The signal tone sounds when the required temperature is reached during preheating.
	Signal volume	Levels 1, 2, 3, 4, 5*, 6, 7, 8	Sets the volume of the signal tone
	Time format	AM/PM / 24 h*	Time display in 24 or 12-hour format
\odot	Time	Current time	Setting the time

⊗ *	Daylight savings	Manual*/Automatic	Automatic time changeover when changing daylight savings time. If automatic: setting of the month, day and week when the time is to be changed. To be set separately for summer and winter time.
	Date format	D.M.Y*	Setting the date format
31		D/M/Y	
		M/D/Y	
31	Date	Current date	Setting the date. Switch between the year/month/day with the > symbol.
	Temperature unit	°C* / °F	Setting the temperature unit
[4]	Weight unit	kg*/oz.	Set the weight unit
АВС	Language	German* / French [] / English US / English	Selecting the language for the text display
		,g	Note:
			The system will restart if the language is changed. This process takes a few seconds. The basic settings menu is then closed.
	Factory settings	Restore appliance to factory set- tings	Confirm the question "Delete all individual settings and restore appliance to factory settings?" with \checkmark or cancel with x .
			Note:
			Note: When restoring factory settings, the personal recipes are also deleted.
			When restoring factory settings, the personal recipes are also deleted. After restoring the factory settings, you will see the "Initial settings" menu.
*	Demo mode	On/Off*	When restoring factory settings, the personal recipes are also deleted. After restoring the factory settings, you will
*	Demo mode	On/Off*	When restoring factory settings, the personal recipes are also deleted. After restoring the factory settings, you will see the "Initial settings" menu. For presentation purposes only. The appliance does not heat in the demo mode, but all other
	Demo mode Sabbath mode	On/Off* Not available*/Available	When restoring factory settings, the personal recipes are also deleted. After restoring the factory settings, you will see the "Initial settings" menu. For presentation purposes only. The appliance does not heat in the demo mode, but all other functions are available. The "Off" setting must be activated for normal operation. The setting is only possible in the first three minutes after connecting the appli-
			When restoring factory settings, the personal recipes are also deleted. After restoring the factory settings, you will see the "Initial settings" menu. For presentation purposes only. The appliance does not heat in the demo mode, but all other functions are available. The "Off" setting must be activated for normal operation. The setting is only possible in the first three minutes after connecting the appliance.
	Sabbath mode Display estimated cooking time with core temperature	Not available*/Available	When restoring factory settings, the personal recipes are also deleted. After restoring the factory settings, you will see the "Initial settings" menu. For presentation purposes only. The appliance does not heat in the demo mode, but all other functions are available. The "Off" setting must be activated for normal operation. The setting is only possible in the first three minutes after connecting the appliance. Available: Sabbath mode can be set. On: Estimated cooking time is shown in the display when the core temperature probe is

en-us Basic settings

<u>@</u>	Home network	Connection type Connection	Settings for the connection to the home network and the mobile devices.
		Ø Connect to app	Different setting options will be displayed depending on the connection status.
		Software update	depending on the connection status.
		a Remote control	
		⊗ Delete network settings	
		Appliance information	
* Factory s	ettings		

Cleaning and maintenance

If taken care of and cleaned conscientiously, your appliance will stay beautiful and intact for a long time. Here we explain how to take care of and clean your appliance correctly.



WARNING

Risk of electrical shock!

Moisture entering the appliance can cause an electrical shock. Don't use a high-pressure cleaner or steam cleaner.



WARNING

Risk of burns!

- To avoid risk of injury, never touch the inside surfaces of the oven interior or heating elements. These surfaces are extremely hot after use. Always allow the appliance to cool down before touching or cleaning the interior.
- Always turn off the interior light before cleaning the oven to allow the bulbs to cool down. The bulbs can become very hot when switched on. Keep the light off while cleaning the oven.
- Keep children away.



WARNING

Risk of injury!

Scratched glass in the appliance door can burst. Do not use any glass scrapers or strong or abrasive cleaning agents.



WARNING

Do not clean the appliance while it is still hot. Some cleaners produce noxious fumes when applied to a hot surface. Wet clothes and sponges can cause burns from steam.

Cleaning agents

Pay attention to the information in the table to ensure that the various surfaces are not damaged by incorrect cleaning agents.

Do not use any

- sharp or abrasive cleaning agents
- metal or glass scrapers to clean the glass on the appliance door.
- metal or glass scrapers to clean the door seal.
- hard abrasive pads or cleaning sponges.

Thoroughly rinse out new sponge cloths before use.

Area	Cleaning agent				
Door panels	Glass cleaner: Clean with a soft cloth or a microfiber cloth. Do not use a glass scraper.				
Display	Wipe down using a microfiber cloth or a slightly damp cloth. Do not wipe with a wet cloth.				
Stainless steel	Hot soapy water: Clean with a dish cloth and dry with a soft cloth. Remove flecks of lime scale, grease, starch, and albumin (e.g., egg white) immediately. Corrosion can form under such flecks. Special stainless steel cleaning agents are available from customer service or from specialist retailers.				
Aluminum	Clean with a mild window cleaning agent. Using a window cloth or a lint-free microfiber cloth, wipe over the surfaces lightly in a horizontal direction.				
Cooking compartment	Hot soapy water: Clean with a dish cloth and dry with a soft cloth.				
Very dirty cook- ing compart- ment	Cleaning gel spray for ovens (order number 00311860 from customer service or in the online shop).				
	 Please note: Must not come into contact with the door seal. Leave for no more than 12 hours. Do not use on hot surfaces. Rinse thoroughly with water. Observe the manufacturer's instructions. 				
Glass cover for the cooking compartment light	Hot soapy water: Clean with a dish cloth.				
Door seal Do not remove.	Hot soapy water: Clean with a dish cloth, do not scour. Do not use a metal or glass scraper for cleaning.				
Core tempera- ture sensor	Wipe with a damp cloth. Do not place in the dishwasher.				
Accessories	Hot soapy water: Soak and clean with a dish cloth or brush.				

Area	Cleaning agent
Plug-in grids	Dishwasher, see section → "Removing the plug-in grid" on page 40
Rotary spit (not available with all oven models)	Hot soapy water: Clean with a dish cloth or brush. Do not soak or clean the rotary spit drive in the dishwasher.
Telescopic shelf (Optional accessory)	Hot soapy water: Clean with a dish cloth or brush. Do not soak or clean in the dishwasher.
Baking stone (Optional accessory)	Clean burnt-on residues with a brush. Never clean the baking stone when it is wet.
Roasting dish (Optional accessory)	Hot soapy water: Soak and clean with a dish cloth or brush. Do not clean the roasting dish in the dishwasher.

Microfiber cloth


The honeycomb microfiber cloth is particularly suitable for cleaning sensitive surfaces such as glass, glass ceramic, stainless steel or aluminum (product no. 00460770, also available from our online online shop). It removes liquid and greasy deposits in one go.

Removing the plug-in grid

The plug-in grids can be removed for cleaning.

Removing the plug-in grids

- 1. Put a dish towel in the cooking compartment to protect the enamel from scratches.
- 2. Loosen the knurled screws (Figure A).
- 3. Remove the plug-in grids (Figure B).



You can clean the plug-in grids in the dishwasher.

Hooking in the plug-in grids

- 1. Attach the plug-in grids all around: longer side toward the top. The right and left grids are identical.
- 2. Tighten the knurled screws.

Pyrolysis (self-cleaning)

During self-clean (pyrolysis), the oven heats up to 905°F (485°C). Thus, remainders from roasting, grilling or baking are burnt up and all you have to do is wipe the ash out of the interior.

Self-clean (pyrolysis) takes three hours. You can move the self-clean switch-off time (for example, if you would like it to run at night).

A

WARNING

During the elimination of soil during self-cleaning, small amounts of Carbon Monoxide can be created and the fiberglass insulation could give off very small amounts of formaldehyde during the first several cleaning cycles. To minimize exposure to these substances, provide good ventilation with an open window, or use a ventilation fan or hood.

Wipe out excessive spillage before self-cleaning the oven.



WARNING

Risk of fire!

The appliance becomes very hot during pyrolytic self-cleaning. Never hang flammable items such as dishcloths on the door handle. Keep the front of the appliance clear. Keep children away.



WARNING

Severe health risk!

The appliance becomes very hot during pyrolytic self-cleaning. The non-stick coatings on trays and forms are destroyed and toxic gases are produced. Never leave trays and forms with non-stick coatings in the oven during pyrolytic self-cleaning. Only leave enameled accessories in oven during self-clean cycle.



WARNING

Risk of burns!

The oven interior becomes very hot during pyrolytic cleaning. Never open the appliance door or the latching hook by hand. Allow the appliance to cool down. Keep children away.



WARNING

Risk of burns!

The appliance will become very hot on the outside during the cleaning function. Never touch the appliance door. Allow the appliance to cool down. Keep children away from the appliance.

Do not clean parts or accessories in the self-clean oven.

Preparing the pyrolytic self-cleaning feature



CAUTION

Risk of fire! Loose food remnants, fat and meat juices may catch fire. Wipe the cooking compartment with a damp cloth.

- Remove the worst soiling and food residues from the
- Clean the door seals, the inside of the door and the glass pane by hand as these parts are not cleaned during the pyrolytic self-cleaning cycle.
- Remove any loose parts from inside the cooking compartment. The plug-in grids are pyrolysis-proof. Make sure that nothing is left inside the cooking compartment.
- Bush for the additional heating element at the back of the cooking compartment: Make sure that the cover is in the bush.
- Close the oven door.

Starting the pyrolytic self-cleaning function

- 1. Set function selector to S.
- 2. The √ + symbol is displayed. Press ✓ to confirm.
- 3. The switch-off time at which the pyrolytic self-cleaning function will be finished is displayed. If desired, change the switch-off time with the rotary selector. Press to confirm.
- 4. Remove all accessories from the oven cavity and remove any coarse dirt. Press V to confirm.
- Press > to start. The cleaning time counts down on the display. If the switch-off time has been delayed, the time until the pyrolytic self-cleaning function starts counts down in the display. The light in the oven cavity remains switched off.



A signal sounds once the pyrolytic self-cleaning function has ended. A message appears in the display. Once the appliance has cooled down, wipe out the ash that has been left behind in the oven cavity with a damp cloth.

Notes

- The total duration of the pyrolytic self-cleaning function comprises the cleaning time and cooling period. The time for the relevant section of the pyrolytic self-cleaning function counts down on the display.
- For safety reasons, the oven door locks automatically. During cooling, the door mechanism is opened as soon as the temperature falls below 390°F (200 °C).

Depending on the type of soiling, white deposits may remain on the enamel surfaces. These deposits are residue from the food and are harmless. They do not affect how the appliance works. If required, you can remove these residues using lemon juice and a soft cloth.

Cleaning the Accessories with the Pyrolytic Self-cleaning Feature

Gaggenau baking trays and broiler pans are coated with pyrolysis-resistant enamel. For optimal results when cleaning the oven, we recommend removing all accessories from the oven before initiating the pyrolytic self-cleaning feature. This is the only way to achieve even heat distribution.

If you wish to remove burnt-on residue from your baking tray or broiler pan with the pyrolytic self-cleaning cycle, please observe the following instructions:

Notes

- Remove the worst soiling, meat juices, and food residues before initiating the pyrolytic self-cleaning cycle. Food residues, grease, and meat juices may catch fire during the pyrolytic self-cleaning cycle.
- Slide only one baking tray or broiler pan onto the lowest rack in the oven.
- Push the baking tray or broiler pan in as far as it will go.
- Wire rack, rotisserie spit, cast iron roaster, baking stone, core temperature sensor, or other accessories must not be cleaned in the pyrolytic self-cleaning cycle.
- Broiler pans with stainless steel bushings can discolor during the pyrolytic self-cleaning cycle. This does not affect its usability.

Disruption	Possible cause	Solution
Appliance not working, no display	Plug not inserted	Connect the appliance to the electricity mains
	Power failure	Check whether other kitchen appliances are working
	Fuse defective	Check in the fuse box whether the fuse for the appliance is in working order
	Operating error	Switch off the fuse for the appliance in the fuse box and switch it on again after about 10 seconds
Appliance cannot be started	Appliance door is not quite closed	Close appliance door
Appliance is not working, display is not responding. appears in the display.	Child lock activated	Deactivate child lock (see section enti- tled 'Child lock')
Appliance switches off automatically	Safety deactivation: the appliance has not been operated for longer than 12 hours	Confirm the message with , switch off the appliance and set it again.
Appliance does not heat up, 🗲 appears in the display	Appliance is in the demo mode	Deactivate demo mode in the basic settings
Error message "Exxx"		If an error message appears, turn the program selection to 0; if the display goes off, it was a one-time problem. If the problem occurs repeatedly or if the display stops, please contact after-sales service and inform them of the error code.

Power cut

Your appliance can bridge a power cut of a few seconds. Operation continues.

If the power cut was for a longer period and the appliance was in operation, a message appears in the display. Operation is interrupted.

Set the function selector to **0**, then the appliance can be operated again as usual.

Demo mode

The demo mode is activated if the *\infty\$ symbol appears in the display. The appliance does not heat up.

Briefly disconnect the appliance from the mains (switch off the domestic fuse or the circuit-breaker in the fuse box). Then deactivate the demo mode within 3 minutes in the factory setting.

"Basic settings" on page 36

Replacing the oven lamp

You can replace the oven lamps. You can obtain replacement lamps after-sales service or from trade dealers. Use the same type of halogen bulbs only.

Top lamp: 60 W/230 V/G9

• Side lamp: 10 W/12 V/G4



WARNING

Risk of electric shock!

When you replace the oven interior lamp, the contacts of the lamp holder are live. Before replacing the lamp, remove the power plug or deactivate the circuit breaker or fuse in the fuse box.



WARNING

Risk of burns!

Lamps become very hot when switched on. There is still a risk of burning your skin for some time after they have been switched off. Allow lamps to cool down before replacing them.

Note: Always use a dry cloth to remove the halogen lamp from its packaging. This lengthens the lamp's useful life.

Replacing the top oven lamp

- Undo the screw on the lamp cover. The lamp cover folds down.
- Take out the halogen lamp. Insert the new halogen lamp.
- 3. Fold up and screw down the lamp cover.
- 4. Switch on the fuse in the fuse box again.

Replacing the side oven lamp

- 1. Place a dishcloth in the oven to avid damage.
- Undo the knurled screws on the slide-in rack. Remove the slide-in rack.
- Press the top retaining spring to the side. Remove the glass cover.
- 4. Take out the halogen lamp. Insert the new halogen lamp.
- 5. Insert the glass cover at the bottom into the retaining spring and latch it at the top. The beveled side of the glass cover must point toward the oven.
- 6. Remove the dishcloth from the oven.
- 7. Switch on the fuse in the fuse box again.

Replacing the glass cover

The glass cover in the oven must be replaced if it is damaged. You can obtain covers from after-sales service. Always specify the E number and the FD number of your appliance.

Customer service


If your appliance needs repairs, our customer service is there for you. We work hard to help solve problems quickly and without unnecessary service calls, getting your appliance back up and running correctly in the least amount of time possible.

When you call, please indicate the product number (E-Nr.) and serial number (FD-Nr.) so that we can support you in a qualified manner. You will find the type plate with these numbers on the bottom of the appliance. To avoid having to search for a long time when you need it, you can enter your appliance data and the customer support telephone number here.

E-Nr.	FD-Nr.	
-------	--------	--

Customer Service ®

Please read the use and care instructions provided with your appliance. Failure to do so may result in an error in using the appliance. This could result in a service call that instead of fixing a mechanical issue is only needed for customer education. Such calls are not covered by the appliance warranty.



Please find the contact data of all countries in the enclosed customer service list.

To book a service visit and product advice

USA 877 442 4436

toll-free

CANADA 877 442 4436

toll-free

Tables and tips

Notes

- Always preheat the appliance.
 This will produce the best cooking results. The cooking times specified refer to a preheated appliance.
- The values specified are intended as a guide. The actual cooking times depend on the quality and temperature of the food before cooking and the weight and thickness of the food to be cooked.
- The tables list temperature and/or time ranges. Try the lowest value to start. You can always choose a longer time next time if required.
 - A lower temperature results in more even browning. If necessary, set a higher temperature.
- The specifications refer to average quantities for four people. If you would like to prepare more, you should calculate a longer cooking time.
- Use the cookware specified. If you use other cookware, cooking times may be longer or shorter.
- You may use any heat-resistant cookware. Place the cookware in the center of the wire rack. For large roasts, you can also use the grill or glass tray.
- Do not place too many items close together on the wire racks or baking trays. This guarantees optimal heat circulation.
- To prepare bulky food items, you can remove the shelf supports at both sides. Place the wire rack directly onto the bottom of the oven cavity and place the food or roasting dish onto the wire rack. Do not place the food or roasting dish directly onto the enamel bottom of the oven cavity. Open the door of the preheated oven for a short time only when placing food inside the oven cavity.
- The details for the level refer to the slide-in level from below for appliances with 4 slide-in levels. The values in brackets refer to appliances with 5 slide-in levels.
- When removing glass cookware from the oven, set it down on a dry hot pad, never on a cold or wet surface.
 Otherwise, the glass may crack.
- Some operating modes are not available with all oven models or only with special accessories.
- Eco hot air:

Energy-saving hot air mode for cakes, meats, casseroles, and gratins. Residual heat is optimally used. Convenience functions remain switched off (e.g the interior lighting). The interior temperature can only be displayed while the appliance is heating up. Do not preheat the oven.

Make sure that the oven cavity is cold and that there is nothing already in there when you place the food inside. Then start the specified cooking time. Always keep the appliance door closed when cooking. This prevents heat loss.

• Full surface grill and full surface grill + circulated air:

With these operating modes, there may be a temperature difference between the temperature you have set and the actual temperature inside the oven. This is because grilling and browning are fast cooking processes that require high temperatures. Consequently, for browning and roasting, a higher temperature than is actually needed on the surface of the food is selected.

Vegetables

- Vegetables from the oven are a good alternative to vegetables from the pan. The flavors are concentrated and the roasting aromas make them very aromatic.
 Furthermore, very little fat is required for preparation.
- Wash the vegetables and mix them in a bowl with a little oil. Place in a heat-resistant pan or distribute evenly in the glass/grill tray.
- During cooking, stir at least once. After cooking, adjust the spices and flavor to taste with fresh herbs.
- Vegetables are suitable as warm or cold appetizers or vegetarian main dishes, or also as side dishes to be served with fish and meat.
- For small portions (for 2-3 people), use an ovenproof dish and place it on the wire rack. Otherwise the food will burn or dry out in the glass/wire tray.
- Always follow the manufacturer's instructions for precooked and frozen products.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Vegetable skew- ers	Wire rack + Grill tray	3 (4)	430 (220)	www	24*	Cut wooden skewers short or soak in water overnight so they do not burn.
						Recipe tip: Peppers, onions, corn (precooked), cherry tomatoes, zucchini
Green asparagus, grilled	Glass/grill tray	3 (4)	430 (220)	www	6-10*	Recipe tip: Season with onions, oil, vinegar, salt, and pepper.
Root vegetables	Glass/grill	3 (4)	390 (200)	*	30*	Recipe tip: Season carrots, celery,
	tray	3 (4)	480 (250)	พพพ	15-20*	rutabagas and red beets with oil, salt, and pepper.
Pumpkin pieces	Glass/grill tray	3 (4)	390 (200)	*	20 - 30*	Recipe tip: Season with oil, garlic, ginger, cumin, salt, and pepper.
Antipasti	Glass/grill	3 (4)	390 (200)	*	30*	Recipe tip: Drizzle balsamic vinegar
	tray	3 (4)	480 (250)	www	15-20*	over the vegetables while they are still hot, and season them.
Escalivada (Mediterranean oven-roasted veg- etables)	Ovenproof dish	4 (5)	480 (250)	www	15*	Recipe tip: Aubergines, onions, tomatoes, peppers, oil. Delicious hot or cold.
Ratatouille	Glass/grill tray	3 (4)	390 (200)		30-40*	Recipe tip: Sprinkle with parmesan just before serving.
Oven-roasted tomatoes	Ovenproof dish	2 (3)	250 (120)	*	60	Recipe tip: Place cherry tomatoes or sliced tomatoes, rosemary, and garlic into the baking dish and drizzle with oil and a little honey.
						If you wish, you can blanch the tomatoes and peel them beforehand.
Chicory	Ovenproof dish	2 (3)	355 (180)	*	25-30	Recipe tip: Halve, season, wrap in boiled ham, pour cream or béchamel sauce over the top and sprinkle with cheese.
		2 (3)	375 (190)	♣°	45-50	No need to preheat; do not open appliance door.
Stuffed pep- pers,Stuffed pep- pers, vegetarian	Ovenproof dish/roast- ing dish	2 (3)	375 (190)		50	Recipe tip: Stuff with boiled rice, soft wheat or lentils and onions, cheese, herbs and seasoning/spices.

Turn the food halfway through the cooking time.

Side dishes and dishes

- The best side dishes from the oven are based on potatoes, for example potatoes au gratin. However, other outstanding side dishes can also be prepared in the oven, which normally are prepared in the pan (e.g. potato pancakes or fried potatoes). The advantages of this tye of preparation: you can prepare larger quantities at once, the cooking smells are distributed less in the room, and you can prepare the dishes with less fat.
- Another versatile side dish from the oven is cheese.
 Cheese is an especially good addition to vegetarian dishes, or you can prepare the cheese as an appetizer or finger food.
- Dishes that are suited for preparation in the oven are especially dishes that are gratinated, such as casseroles and gratins. Suitable also are dishes with a dough base, e.g. pizza or tarte flambée, and egg dishes such as tortillas.
- For small portions (for 2-3 people), use an ovenproof dish and place it on the wire rack. Otherwise the food will burn or dry out in the glass/wire tray.
- Always follow the manufacturer's instructions for precooked and frozen products.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Side dishes						
Potatoes on a bed of coarse salt	Ovenproof dish	2 (3)	390 (200)		40-60*	Fill the ovenproof dish with 2 cm of sea salt. Place small potatoes in the dish with their skins on and brush them with olive oil.
Potato wedges	Baking tray + Grease- proof paper	2 (3)	390 (200)	*	15*	Recipe tip: Cut the potatoes into wedges and season them with olive oil, paprika and salt.
Chips, fresh	Baking tray + Grease- proof paper	3 (4)	390 (200)	*	15-20*	Recipe tip: Cover with a little oil; season with salt and paprika or curry powder after cooking.
Chips, frozen	Baking tray + Grease- proof paper	3 (4)	430 (220)	*	14*	
Potato gratin	Ovenproof	2 (3)	355 (180)	*	35	
	dish	2 (3)	375 (190)	♣°	55-60	No need to preheat; do not open appliance door.

^{*} Turn the food halfway through the cooking time.

en-us Tables and tips

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Potato pancakes	Baking tray	2 (3)	345 (175)	*	20-30*	Oil the baking tray liberally, squeeze
		2 (3)	390 (200)		20-30*	out the excess liquid from the potato pancake mixture and brush with a little oil. Turn once.
Roasted potatoes	Grill tray	2 (3)	355 (180)	*	30-45*	Low-fat preparation. Distribute evenly on the grill tray, mix several times.
Goats' cheese in a	•	2 (3)	430 (220)	*	8-10	Fresh goat's cheese or goat camem-
bacon blanket	baking tray	3 (4)	430 (220)	www	8-10	bert works well.
Goat's cheese	Glass tray/	2 (3)	390 (200)	*	8	Recipe tip: Drizzle lavender honey over
with honey	baking tray	3 (4)	390 (200)	www	8	the goat's cheese or goat camembert and sprinkle with pine nuts.
Baked camem- bert, breaded, fresh	Baking tray + grease- proof paper	2 (3)	355 (180)	*	15-20	Bake until the breadcrumb coating rises in the centre.
Baked camem-	Baking tray	2 (3)	355 (180)	*	15-20	Bake until the breadcrumb coating
bert, breaded, frozen	+ grease- proof paper	2 (3)	390 (200)		15	rises in the centre.
Mozzarella sticks, frozen	Baking tray + grease- proof paper	2 (3)	355 (180)	*	10	
Feta	Baking tray	2 (3)	480 (250)	\$ CP	12	Recipe tip: Place in a baking dish with oil, tomatoes, onions, garlic and rosemary and season with salt and pepper.
Oven-baked cheese, fresh	Baking tray	2 (3)	355 (180)	*	20	After 10 minutes, cut a cross into the soft cheese and break open. If possible, the baking dish should be not much larger than the cheese so that the cheese does not run.
Dishes						
Tortilla	Ovenproof dish	2 (3)	320 (160)		25	Recipe tip: With paprika, olives, onion, Serrano ham and Manchego cheese.
Farmers' omelette	Ovenproof dish	2 (3)	320 (160)	*	40	Recipe tip: With green and white asparagus; also add gravlax.
Frittata	Ovenproof dish	2 (3)	375 (190)		45-50	Recipe tip: with spinach, onions, and shrimp.
Enchiladas, grilled	Glass dish/ grill tray	2 (3)	390 (200)		15-20	
Lasagne	Ovenproof dish	2 (3)	345 (175)	*	35	Recipe tip: classic or vegetarian with grilled vegetables and Buffalo mozzarella.
		2 (3)	355–375 (180–190)	♣°	55-60	No need to preheat; do not open appliance door.
Macaroni cheese	Ovenproof dish	2 (3)	355/430 (180/220)	*	10-20	For a cheesy crust, increase the temperature to 430°F (220°C) after 10 min. and let brown for 10 min.

^{*} Turn the food halfway through the cooking time.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Cheese spätzle (Swabian noodle dish)	Ovenproof dish	2 (3)	355/430 (180/220)	*	30	Gradually layer the freshly-cooked spätzle in the baking dish, sprinkling each layer with cheese.
						Finally, top with cheese and roasted onions and increase the temperature to 430°F (220 °C) for 5 min.
Spring rolls, frozen	Baking tray + Grease- proof paper	2 (3)	435 (225)	*	18-20*	
Mini spring rolls, frozen	Baking tray + Grease- proof paper	2 (3)	435 (225)	*	10*	
Pizza, fresh	Baking tray	2 (3)	445-480 (230-250)		10-15	Lightly oil the baking tray.
Pizza, pre-baked	Baking tray	2 (3)	445 (230)	*	6-8	
	+ Grease- proof paper	2 (3)	445 (230)		6-8	-
Pizza, frozen	Wire rack	2 (3)	390 (200)	*	11–13	
		2 (3)	445 (230)		11–13	-
American pizza (deep pan), frozen	Baking tray	2 (3)	390 (200)		20-24	Do not preheat.
Tarte flambée, fresh	Baking tray	2 (3)	480 (250)		8–10	Recipe tip: Traditional or with goat's cheese, Parma ham, figs and spring onions.
Tarte flambée, pre-baked	Baking tray + Grease- proof paper	2 (3)	250	*	7	
Tarte flambée,	Wire rack	2 (3)	390 (200)	*	10-12	
frozen		2 (3)	445 (230)		8-10	-
Quiche	Tart tin or dish	2 (3)	390 (200)		20 + 20	Pre-bake crust for 20 min., pour mix- ture into the crust, and bake another 20 min.

Fish

- Fish should (for hygienic reasons) have a core temperature of at least 144 - 158°F (62 - 70 °C) after cooking. This is also the ideal cooking point.
- Only salt the fish after cooking. Thus the natural aroma is retained and less water is removed from the fish.
- Oil the wire rack and baking tray a little bit, then the fish will not stick.
- For fillets with skin: if you place the fish skin-side up, the structure and aroma will be retained better.
- Cut wooden skewers short or soak in water overnight before skewering the ingredients so they do not burn.
- Always follow the manufacturer's instructions for precooked and frozen products.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Shrimp skewers, fresh	Wire rack + Grill tray	3 (4)	355 (180)	www	10*	
Shrimp skewers, frozen	Wire rack + Grill tray	3 (4)	355 (180)	WWW	12*	
Fish kebabs	Wire rack + Grill tray	3 (4)	390 (200)	www	12*	Use firm types of fish, e.g. salmon, coley, ocean perch and cod.
Trout, whole	Baking tray	3 (4)	380-430 (200-220)	พพพ	16*	Recipe tip: Stuff with lemon, garlic, and parsley.
Sea bream, whole	Wire rack + Grill tray	3 (4)	380-430 (200-220)	WWW	20-25*	Recipe tip: Stuff with lemon, garlic and thyme, or use mint for a summery touch.
	Baking tray	3 (4)	375 (190)	*	20-25*	Make a diagonal incision into the skin of the sea bream.
Salmon steak	Wire rack + Grill tray	3 (4)	480 (250)	4	10-12	Recipe tip: Marinate in a mixture of lime, salt, pepper, and garlic.
	Baking tray	2 (3)	390 (200)	*	10-12	-
Tuna steak	Baking tray	2 (3)	390 (200)	*	8-10	Recipe tip: Season Asian-style with soy sauce, sesame oil, ginger, honey, garlic, chili, and coriander seeds.
Fish fingers, frozen	Baking tray + grease- proof paper	2 (3)	430 (220)	*	15–17*	
Squid rings, frozen * Turn the food h.	Baking tray + grease- proof paper	2 (3)	430 (220)		8-12	

Meat

- Use the core temperature sensor so that you can monitor the core temperature more easily. Information and optimum target temperatures can be found in the section entitled → "Core temperature probe" on page 26.
- Leaving meat to rest: Let meat rest for a further 10 15 minutes after cooking. This gives the meat a chance to "relax". The circulation of the meat juice slows down and there is less loss of juice when cutting into the meat. Large pieces of meat, such as roasts, can rest in the oven. Smaller ones, e.g. steaks, should rest outside the oven wrapped in aluminum foil.
- For small portions (2 3 people), use a heat-resistant pan so that the food does not burn or dry out.
- Use the grill tray or the roasting dish for a large roast and for types of preparation that generate a lot of liquid for roasting.
- For best results, leave meat to marinate overnight and remove it before roasting or grilling, e.g. using the back of a knife or a spoon. Otherwise, the herbs and spices will burn.

- If the roast gets too dark and the crust is burned in places, reduce the temperature the next time and check the rack level.
- If the roast is cooked but the sauce is burned on, next time use a smaller roasting dish and add more liquid.
 If the sauce is too watery, next time use a larger roasting dish and add less liquid.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Beef						
Roast beef (3.3 lb /1.5 kg)	Glass/grill tray	2 (3)	355 (180)	¥	90 - 120*	
Rump steak,	Glass/grill	2 (3)	390 (200)	*	30	Core temperature 150° F (65°C)
medium rare (1.1 lb /500 g)	tray	2 (3)	390 (200)	♣ ^e	45 - 50	Core temperature 150° F (65°C). No need to preheat; do not open appliance door.
Roast beef/sirloin (2.2 lb /1 kg) - rare	Glass/grill tray	2 (3)	445 / 355 (230 / 180)	¥	25 - 35**	Recipe tip: tastes very good with Béarnaise sauce or sliced cold with
- medium	Glass/grill tray	2 (3)	445 / 355 (230 / 180)	¥	35 - 45**	remoulade and roasted potatoes.
- well-done	Glass/grill tray	2 (3)	445 / 355 (230 / 180)	*	50 - 60**	
Pork						
Fillet of pork, whole (0.9 lb / 400 g)	Glass/grill tray	2 (3)	445 / 355 (230 / 180)	*	20 - 25**	Recipe tip: marinate with oil, garlic, and parsley.
Fillet of pork	Glass/grill	2 (3)	355 (180)	*	30	Core temperature 160° F (70°C).
(0.6 lb /250 g)	tray	2 (3)	355 (180)	♣°	40 - 45	Core temperature 160° F (70°C). No need to preheat; do not open appliance door.
Pork medallions	Glass/grill tray	2 (3)	410 (210)	₹ <u>}</u>	12 - 15*	Recipe tip: shortly before removing, put a piece of butter and a rosemary sprig in the glass/grill tray and continue cooking in the oven.
Pork roast - joint (2.2 lb /1 kg)	Glass/grill tray	2 (3)	445 / 355 (230 / 180)	¥	45 - 50**	
Pork roast - neck (3.3 lb /1.5 kg)	Glass/grill tray	2 (3)	445 / 355 (230 / 180)	¥	85 - 95**	
		2 (3)	445 / 355 (230 / 180)	₹. \$	70 - 80**	_
Pork roast with crust (3.3 lb /1.5 kg)	Wire rack + Grill tray	2 (3)	355 / 390 (180 / 200)	45 A	60 - 70***	
Pork knuckles	Wire rack + Grill tray	2 (3)	300 / 390 (150 / 200)	₩W.	40 - 45***	Cut roughly into skin so that it gets crusty.
Smoke-cured pork (2.2 lb /1 kg)	Glass/grill tray	2 (3)	355 / 320 (180 / 160)	*	50 - 60**	
Rolled pork	Glass/grill tray	2 (3)	445 / 355 (230 / 180)	ş	65 - 70***	
	Wire rack + Grill tray	2 (3)	445 / 355 (230 / 180)	₹. 24.	75 - 80***	

^{*} First cook thoroughly in a pan/roasting dish on the burner.

^{**} Brown the meat at high temperature, after 15 - 20 min. switch back to a lower temperature.

^{***} Cook meat at a low temperature, set the temperature higher for the last 15 - 20 min.

en-us Tables and tips

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Veal						
Veal roast (3.3 lb /1.5 kg)	Glass/grill tray, roasting dish	2 (3)	445 / 355 (230 / 180)		50 - 60***	
Veal knuckle	Glass/grill tray, roasting dish	2 (3)	300 / 355 (150 / 180)	₩.W.W.	50 - 60***	
Veal loin	Glass/grill tray, roasting dish	2 (3)	320 - 340 (160 - 170)	*	20	
Stuffed breast of veal	Glass/grill tray, roasting dish	2 (3)	250 - 265 (120 - 130)	*	120	
Game						
Wild boar roast	Glass/grill tray, roasting dish	2 (3)	340 (170)	*	60 - 90*	Recipe tip: marinate overnight in oil, garlic, mustard, and herbes de Provence.
Leg of venison	Glass/grill tray, roasting dish	2 (3)	340 - 355 (170 - 180)	*	60 - 80	
Saddle of venison	Glass/grill tray, roasting	2 (3)	330 - 345 (165 - 175)	*	20	
	dish	2 (3)	330 - 345 (165 - 175)		20 - 25	
Saddle of hare or rabbit	Glass/grill tray, roasting dish	2 (3)	355 (180)	4	15 - 25*	Recipe tip: marinate in garlic, rose- mary, olive oil, and high-qualitty bal- samic vinegar.
Leg of lamb - medium	Glass/grill tray, roasting dish	2 (3)	355 - 375 (180 - 190)	*	100*	Recipe tip: marinate overnight in olive oil, garlic, rosemary, and lemon peel.
- well-done	Glass/grill tray, roasting dish	2 (3)	355 - 375 (180 - 190)	*	120*	
Knuckle of lamb	Glass/grill tray, roasting dish	2 (3)	355 - 390 (180 - 200)	*	35 - 45	
Miscellaneous						
Meatballs (2.8 oz /80 g each)	Baking tray + greaseproof paper	2 (3)	390 (200)	*	30 - 35	The flatter the meatballs are, the quicker they will cook. Well-suited for large quantities.
Meatballs, cooked (2.8 oz /80 g each)	Baking tray + greaseproof paper	2 (3)	390 (200)	*	20	Well-browned and yet juicy meat- balls: first cook in the pan and then put in the oven.
Meatballs (0.8 oz /25 g each)	Baking tray + Greaseproof paper	2 (3)	390 (200)	*	25 - 30	Recipe tip: very good for further combinations, e.g. meatballs with tomato sauce, Swedish meatballs, Königsberger meatballs.

^{*} First cook thoroughly in a pan/roasting dish on the burner.

^{**} Brown the meat at high temperature, after 15 - 20 min. switch back to a lower temperature.

^{***} Cook meat at a low temperature, set the temperature higher for the last 15 - 20 min.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Meatballs, cooked (0.8 oz /25 g each)	Baking tray + Greaseproof paper	2 (3)	390 (200)	*	15	Recipe tip: put meatballs of lamb or rabbit on a skewer and serve with minted yogurt or fig mustard.
Head cheese, fresh (1.5 lb /700 g)	Wire rack + Grill tray	2 (3)	320 (160)	*	60	Use core temperature sensor (core temperature 153°F (67°C).
Bacon strips, thin	Baking tray + Greaseproof paper	3 (4)	355 (180)	*	8 - 10	After taking out, let drip on a paper towel.
Bacon strips, thick	Baking tray + Greaseproof paper	3 (4)	375 (190)	*	8 - 12	
Stuffed peppers with ground meat	Ovenproof dish/roasting dish	2 (3)	375 (190)		55 - 60	Recipe tip: fill with ground meat and cook in tomato sauce.

^{*} First cook thoroughly in a pan/roasting dish on the burner.

Poultry

- For better results, use the core temperature sensor.

 Do not place it in the middle (hollow space), but rather between the belly and upper thigh. For notes and optimal target temperatures, see chapter → "Core temperature probe" on page 26
- Poultry will turn out particularly crispy and brown if you baste it towards the end of the roasting time with butter, salted water, drippings or orange juice.
- When cooking duck or goose, pierce the skin on the underside of the wings to allow the fat to run out.
- Use a roasting dish or another heat-resistant pan for dishes that generate a lot of liquid for roasting. The same applies if a lot of fat can run out of the food, e.g. with roast goose.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Duck, whole (3.3 - 4.4 lb /1.5 - 2 kg)	Wire rack + Grill tray/ roasting dish	2 (3)	320 / 355 (160 / 180)		75*	Recipe tip: fill with oranges, apples or dried fruit.
Duck breast	Roasting dish/oven- proof dish	2 (3)	375 (190)	\$ 65 A	25 - 35	Tear skin roughly.
Goose, whole (11 lb /5 kg)	Wire rack + Grill tray/	2 (3)	320 / 375 (160 / 190)	*	110 - 130*	Recipe tip: fill with apples, onions, and marjoram and pierce.
	roasting dish	2 (3)	320 / 375 (160 / 190)		110 - 130*	_
Turkey hen, whole	Wire rack + Grill tray/	2 (3)	390 / 320 (200 / 160)	*	120 - 180*	
	roasting dish	2 (3)	390 / 320 (200 / 160)		120 - 180*	_

^{*} Cook meat at a low temperature, set the temperature higher for the last 15 - 20 min.

^{**} Brown the meat at high temperature, after 15 - 20 min. switch back to a lower temperature.

^{***} Cook meat at a low temperature, set the temperature higher for the last 15 - 20 min.

^{**} Turn food halfway through the cooking time.

en-us Tables and tips

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Chicken, whole	Wire rack +	2 (3)	375 (190)	*	70 - 80	Preheat
	Grill tray	2 (3)	375 (190)	255	70 - 80	
Chicken, legs and	Wire rack +	3 (4)	430 (220)	www	30**	Recipe tip: Asian marinade with soy
thighs	Grill tray	3 (4)	430 (220)	& ₩₩₩	30**	sauce, honey, chili, garlic, ginger, cumin, lime rub, coriander.
Chicken legs Wire rack	Wire rack +	3 (4)	430 (220)	www	30**	After turning, the side with more skin
	Grill tray	3 (4)	430 (220)	255	30**	should be up; this way, it gets crispy.
						Marinate with oil, rosemary, lime wedges, and garlic.
Chicken breast	Wire rack + Grill tray	2 (3)	390 (200)	*	20 - 25	Recipe tip: before cooking, rub with Tandoori paste.
		2 (3)	390 (200)	♣ °	50	No need to preheat; do not open appliance door.
Chicken nuggets, frozen	Baking tray + Greaseproof paper	2 (3)	390 (200)	*	15**	
Breast of quail	Baking sheet	3 (4)	430 (220)	- C.	10 - 12	Baste with oil and spices, e.g. paprika, thyme, juniper, and garlic.
Quail, whole (0.3 lb /150 g each)	Wire rack + Grill tray	3 (4)	390 (200)		20 - 25	Baste with oil and spices, e.g. paprika, thyme, juniper, garlic.

^{*} Cook meat at a low temperature, set the temperature higher for the last 15 - 20 min.

Grilling and roasting

- Do not grill food with the oven door open.
- Use the grill tray with inlaid shelf for grilling (depending on the version, accessory or special accessory). Pour approximately 100 ml water into the grill tray; this will catch the meat juices so that the oven stays clean. If you pour in too much water, this may alter the cooking result because too much steam will be produced.
- The pieces of food to be grilled should be of roughly the same thickness (at least 2 to 3 cm). This will allow them to brown evenly and remain succulent and juicy. Never add salt to meat before grilling it. Place the pieces to be grilled directly on the wire rack.
- If you use wooden skewers, these can burn. In order to prevent this, cut the skewers as short as possible or soak them overnight in water before spearing the ingredients, or use metal skewers.
- For small quantities, use the energy-saving "Compact grill" heating function. With this heating function, only the center part of the grill is heated. Place the food to be grilled in the middle of the wire rack.

Dish	Accessories	Level	Recommend- ed tempera- turein °F (°C)	Type of heating	Cooking time in min.	Comments
Pork belly,	Wire rack +	2 (3)	445 (230)	www	18 - 20*	
sliced	grill tray	2 (3)	445 (230)	£.	18 - 20*	_
Shish kebab	Wire rack + grill tray	3 (4)	375 (190)	365	16*	

^{*} Turn the food halfway through the cooking time.

^{**} Turn food halfway through the cooking time.

^{**} Brown to the level you require.

Dish	Accessories	Level	Recommend- ed tempera- turein °F (°C)	Type of heating	Cooking time in min.	Comments
Bratwurst (Ger- man sausage)	Wire rack + grill tray	3 (4)	520 (270)	www	10*	
Merguez sausage	Wire rack + grill tray	3 (4)	480 (250)	\$\$ ₩₩₩	12*	
Spare ribs, pre-cooked	Wire rack + grill tray	3 (4)	390-430 (200-220)	www	24*	
		3 (4)	390-430 (200-220)	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	24*	
Spare ribs,	Wire rack +	3 (4)	430 (220)	www	40*	Recipe tip: Place in a mixture of oil,
raw	grill tray	3 (4)	430 (220)	\$ 65 8	30*	mustard, balsamic vinegar, honey, garlic, Worcester sauce, tomato purée and Tabasco sauce.
Chicken satay	Wire rack + grill tray	3 (4)	480 (250)	S. W.W.	10 - 14*	Serve with satay sauce.
Halloumi cheese (Grill cheese)	Wire rack + grill tray	3 (4)	480 (250)	\$ 65 \$ 55 \$ 55 \$ 55 \$ 55 \$ 55 \$ 55 \$ 55	5 - 8	Halloumi is a firm cheese that is used in Turkish and Greek cuisine. It is very well-suited for grilling.
Toasting bread (Appliance width: 24 in / 60 cm)	Wire rack	3	390 (200)	www	2:30 - 3	Preheat for up to 5 minutes. Stay by the appliance so that the toast does not brown too much. Do not grill food with the oven door open.
Toasting bread (Appliance width: 30 in /76 cm)	Wire rack	4	390 (200)	www	2 - 2:30	Preheat for up to 5 minutes. Stay by the appliance so that the toast does not brown too much. Do not grill food with the oven door open.
Toast Hawaii	Baking tray + greaseproof paper	3 (4)	375 (190)	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	8 - 10**	
Croque monsieur	Baking tray + greaseproof paper	3 (4)	375 (190)	\$ 65 S	8 - 11**	
Croutons	Baking tray	2 (3)	355 (180)	*	15*	Recipe tip: Mix fresh white bread with olive oil, garlic and rosemary leaves.
						Do not use too much oil, and do not pour it on until you are ready to serve so that the bread cubes do not get soggy. Turn several times.
Browning meringue	Springform cake tin	2 (3)	430-480 (220-250)	www	4 - 5**	Stay by the appliance so that the meringue does not brown too much.
Dried plums wrapped in bacon	Baking tray + greaseproof paper	3 (4)	390 (200)	www	8 - 10	Also tastes good with dates or apricots.

Turn the food halfway through the cooking time.

^{**} Brown to the level you require.

Baked goods

- We recommend dark pans of metal since these absorb the heat better. Place the pan in the middle of the wire rack.
- For sheet cakes without greaseproof paper, oil the pan slightly.
- Small baked items such as cream puffs, cookies or pastries can be baked on two levels, 1+3 or 2+4.
- If you bake on several levels it is normal that the trays are not done at the same time. Leave the lower trays bake a little longer or put them in the oven earlier the next time.
- Before cutting, let the baked goods cool on a rack.
- If the baked goods are too dark on the bottom: insert one level higher, select a lower temperature.

If the baked goods are too dark on the top: insert one level lower, select a lower temperature, and extend the baking time a bit.

- If the cake is too dry, set the temperature a little higher. If the cake is not cooked on the inside, set the temperature a little lower.
 - Baking times cannot be shortened by selecting a higher temperature; it is better to select a somewhat lower temperature.
- If the cake collapses: use less liquid or set the temperature 50°F (10 °C) lower. Do not open the oven door too soon.
- The cake rises only in the middle: grease the edges of the pan.
- If the cookies are hard to take off the sheet, insert the sheet in the hot oven again and remove the cookies while they are still warm.
- If the cake does not come out of the pan when yhou turn it over, use a knife to loosen the cake around the edges. Turn the cake pan upside down again and cover it several times with a cold, wet cloth. Next time, grease the pan well and sprinkle some bread crumbs into it.
- Always follow the manufacturer's instructions for precooked and frozen products.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Cake						
Cheesecake	Springform cake tin	1 (2)	320-330 (160-165)	*	70 - 75	
		1 (2)	320-330 (160-165)		70 - 75	-
		1 (2)	320-330 (160-165)	<u>*</u>	85 - 90	-
		1 (2)	320-330 (160-165)		80 - 90	-
		1 (2)	320-330 (160-165)	<u>*</u>	40 - 45	Cheesecake with half quark filling.
Sponge cake	Springform cake tin	2 (3)	320-340 (160-170)	*	50 - 60	
		2 (3)	320-340 (160-170)		50 - 60	-
Loaf cakes	Loaf tin	2 (3)	320-340 (160-170)	*	60 - 65	To ensure even browning, place the tin lengthwise in the cooking compart-
		2 (3)	320-340 (160-170)		55 - 60	ment.

^{*} Pre-heat the appliance to the specified temperature. When putting in the food to be cooked, switch back to the second specified temperature.

^{**} Deactivate the "Rapid heating" function in the basic settings → "Basic settings" on page 36

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Bundt cake, Ring cake	Ring cake tin	1 (2)	330 (165)	*	30	Recipe tip: Classic Bundt cake or with bacon and walnuts.
		1 (2)	340 (170)	* °	55	No need to preheat; do not open appliance door.
Tray bakes	Baking tray	2 (3)	330-340 (165-170)	*	20 - 30	Oil the baking sheet slightly.
		2 (3)	330-340 (165-170)		40 - 50	-
Swiss roll	Baking tray + greaseproof paper	2 (3)	375 (190)	*	6	Place dough on greaseproof paper sprinkled with sugar, then roll up.
Sponge base	Springform cake tin	2 (3)	300 (150)	*	40 - 45	Line a springform cake tin with grease- proof paper.
Yeast tray bake	Baking tray	2 (3)	330 (165)	*	30 - 35	Recipe tip: Top with plums, figs or
-		2 (3)	330 (165)		30 - 35	onions and bacon.
Fruit flan on a	Tart tin or	2 (3)	330 (165)	*	40 - 50	Recipe tip: Top with strawberries or
shortcake base	dish	2 (3)	340 (170)		40 - 50	with apricots and marzipan.
		2 (3)	330 (165)	*	45 - 55	-
Tart	Tart tin or	2 (3)	375 (190)	*	30 - 40	French flan with a shortcake base, e.g.
	dish	2 (3)	375 (190)		30 - 40	tarte aux pommes, tarte tatin, tarte au
		2 (3)	375 (190)	<u>*</u>	40 - 45	chocolat, tarte au citron.
		2 (3)	375 (190)		45 - 50	For light-colored tart tins or dishes.
Puff pastry strudel	Baking tray + grease- proof paper	2 (3)	390 (200)	*	20 - 25	Recipe tip: Fill with custard and cherries or apples.
Apple pie	8" (20 cm)	2	320**	*	90 - 105	Preheat
(Appliance width: 24 in / 60 cm)	springform cake tin		(160**)			
,,	8" (20 cm) springform cake tin	1	320** (160**)		90 - 100	Preheat
Apple pie (Appliance width: 30 in / 76 cm)	8" (20 cm) springform cake tin	3	320** (160**)	*	85 - 100	Preheat
00 m / 70 cm/	8" (20 cm) springform cake tin	2	320** (160**)		100 - 110	Preheat
Water sponge cake (Appliance width: 24 in / 60 cm)	101/4" (26 cm) springform cake tin	2	320** (160**)	*	22 - 30	Preheat
2+ III / 00 CIII)	101/4" (26 cm) springform cake tin	2	320** (160**)		20 - 30	Preheat

^{*} Pre-heat the appliance to the specified temperature. When putting in the food to be cooked, switch back to the second specified temperature.

^{**} Deactivate the "Rapid heating" function in the basic settings \rightarrow "Basic settings" on page 36

en-us Tables and tips

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Water sponge cake (Appliance width: 30 in / 76 cm)	10¼" (26 cm) springform cake tin	3	320** (160**)	*	22 - 30	Preheat
30 m / 70 om/	101/4" (26 cm) springform cake tin	3	320** (160**)		25 - 30	Preheat
Small baked item	s					
Cream puffs,	Baking tray	2 (3)	355 (180)	*	35	Recipe tip: Fill with vanilla cream,
eclairs	+ grease-	2 (3)	355 (180)		40	chocolate mousse, fruit or mocha
	proof paper	2 (3)	355 (180)	*	35	cream.
Biscuits,	Baking tray	2 (3)	160 - 170	*	15	
Viennese whirls		2 (3)	160 - 170		18	-
Small baked puff- pastry items	Baking tray +	2 (3)	390 (200)	*	15 - 20	
	greaseproof paper					
Filled puff pastry parcels	Baking tray +	3 (4)	390 (200)	¥	15	Recipe tip: Fill with ham and cheese or apples and raisins.
	greaseproof paper					
Puff pastry	Baking tray + greaseproof	3 (4)	390 (200)	*	15	Recipe tip: With sesame seed, poppy, sugar topping.
	paper					
Puff pastry twists	Baking tray + greaseproof	3 (4)	390 (200)	*	15	Recipe tip: With ham, cheese, nuts.
	paper					
Puff pastry slices	Baking tray	2 (3)	390 (200)	*	15 - 20	Recipe tip: Serve with custard and/or fruit.
	greaseproof paper					
Waffle biscuits	Baking tray +	2 (3)	285 (140)	*	8 - 10	Shape the dough while it is still hot, e.g. into horns or rolls for dessert.
	greaseproof paper					
Breadsticks	Baking tray + greaseproof	2 (3)	320 (160)	*	30	Sprinkle with sea salt, rosemary, curry powder, sesame seeds or caraway seeds.
	paper					
Cookies (0.7 oz / 20 g each)	Baking tray + greaseproof	2 (3)	345 (175)	*	12 - 14	With chocolate, raisins, nuts, or lemon
	paper					

^{*} Pre-heat the appliance to the specified temperature. When putting in the food to be cooked, switch back to the second specified temperature.

^{**} Deactivate the "Rapid heating" function in the basic settings \rightarrow "Basic settings" on page 36

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Brownies	Baking tray + greaseproof paper	2 (3)	250 (120)	*	60	After baking, cut into squares. The low temperature means that the brownies retain a slightly sticky consistency in the middle.
		2 (3)	355 (180)	♣°	40 - 45	No need to preheat; do not open appliance door.
Muffins	Muffin tray/	2 (3)	320 (160)	*	25 - 30	With chocolate, nuts, or raisins.
	paper	2 (3)	320 (160)		25 - 30	-
	cases	2 (3)	320-330 (160-165)	-	25 - 30	-
Small cakes (Appliance width:	Glass tray	2	300** (150**)	*	25 - 30	Preheat
24 in / 60 cm)	Baking tray	3	300**	*	28 - 32	Preheat
,	Glass tray	1	(150**)			Application on two levels
	Glass tray	3	320** (160**)		20 - 25	Preheat
Small cakes (Appliance width:	Glass tray	3	300** (150**)	*	26 - 32	Preheat
30 in / 76 cm)	Baking tray	4	300**	*	30 - 32	Preheat
, ,	Glass tray	2	(150**)			Application on two levels
	Glass tray	4	320** (160**)		23 - 24	Preheat
Viennese whirls (Appliance width:	Baking tray	2	285** (140**)	*	35 - 40	Preheat
24 in / 60 cm)	Baking tray	3	285**	*	35 - 40	Preheat
,	Glass tray	1	(140**)			Application on two levels
	Baking tray	2	285** (140**)		26 - 30	Preheat
Viennese whirls (Appliance width:	Baking tray	3	285** (140**)	*	30 - 35	Preheat
30 in / 76 cm)	Baking tray	4	285**	*	30 - 40	Preheat
,	Glass tray	2	(140**)			Application on two levels
	Baking tray	3	285** (140**)		30 - 35	Preheat
Bread, rolls						
Multi-grain bread	Baking tray +	2 (3)	390/340* (200/170*)	*	40 - 50	
	greaseproof paper	2 (3)	390/340* (200/170*)		40 - 50	-
		2 (3)	390/330* (200/165*)	 -	45 - 50	-
Sourdough bread	Baking tray	2 (3)	390/355* (200/180*)		50 - 60	
Olive-tomato bread	Baking tray	2 (3)	390/340* (200/170*)		40 - 50	

^{*} Pre-heat the appliance to the specified temperature. When putting in the food to be cooked, switch back to the second specified temperature.

^{**} Deactivate the "Rapid heating" function in the basic settings \rightarrow "Basic settings" on page 36

en-us Tables and tips

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Bread, in loaf pan	Loaf tin	2 (3)	345 (175)		40 - 45	
Baguette, pre-baked	Baking tray +	2 (3)	430 (220)		10 - 12	
	greaseproof paper					
Ciabatta,	Baking tray	2 (3)	375 (190)		12 - 14	_
pre-baked	+ greaseproof paper	2 (3)	355 (180)	*	12 - 14	
Flatbread	Baking tray	2 (3)	390 (200)	*	15 - 20	The cooking time depends on the size
	+ greaseproof paper	2 (3)	410 (210)		15 - 20	and thickness of the flatbread.
Foccacia	Baking tray + greaseproof	2 (3)	410 (210)		15 - 20	Top with various ingredients, e.g. herbs, sea salt, olives, anchovies, onions, ham, tomatoes, or cheese.
	paper					
Garlic/herb baguette	Baking tray +	2 (3)	390 (200)		8 - 10	
	greaseproof paper					
Puff pastry strudel	+ greaseproof	2 (3)	390 (200)	*	20 - 25	Recipe tip: Fill with sheep's milk cheese and feta.
Plaited loaf	Paper Baking tray	2 (3)	330 (165)	*	20	
Tianed loar	+	2 (3)	340 (170)	**	30 - 35	No need to preheat; do not open appli-
	greaseproof paper	_ (0)	()	•		ance door.
Rolls,	Baking tray	2 (3)	410 (210)		8 - 10	_
pre-baked	+ greaseproof paper	2 (3)	390 (200)	*	8 - 10	
Rolls,	Baking tray	2 (3)	355 (180)	*	10 - 12	
frozen	+ greaseproof paper	2 (3)	390 (200)		10 - 12	-
Rolls, fresh (1.7 oz /	Baking tray +	2 (3)	480/390* (250/200*)		15 - 20	
50 g each)	greaseproof paper					
Pretzel products, frozen	Baking tray + greaseproof paper	2 (3)	390 (200)	*	10 - 12	
Croissants, frozen	Baking tray + greaseproof paper	2 (3)	340 (170)		15 - 25	

^{*} Pre-heat the appliance to the specified temperature. When putting in the food to be cooked, switch back to the second specified temperature.

^{**} Deactivate the "Rapid heating" function in the basic settings \rightarrow "Basic settings" on page 36

Dough proving (leaving to rise)

- Place the bowl with the dough on the wire rack. Select the "dough proofing" heating function.
- For large quantities, e.g. bread, set the temperature to 100 105°F (38 40°C). This way, the dough rises evenly from the middle to the edges.
- For small quantities of dough, for noodles or rolls, you can set the temperature to 105 - 115°F (40 - 45 °C).
- The suggested cooking time is only a guideline. Let the dough proof until its volume has doubled.
- If the dough does not rise, you have used too little yeast or not kneaded the dough enough.

Dish	Accessories	Level	Temperature in °F (°C)		Cooking time in min.	Observations
Dough	Bowl	2 (3)	100 - 115 (38 - 45)	Ō	25 - 45	e.g. yeast dough, natural fementation starter, sourdough, dumplings

Desserts

- Oven-cooked desserts are very easy to prepare you
 just have to put it in the oven. This preparation method
 is well-suited for larger quantities, for example if you
 have guests.
- Oven-cooked desserts are generally eaten warm, and are particularly enjoyable during the cooler months.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Apple Crumble	Ovenproof dish	2 (3)	390 (200)	*	35 - 40	Apple casserole with streusel, also tastes very good when made with berries or mirabelles.
		2 (3)	390 (200)		25 - 30	For soft types of apples.
		2 (3)	390 (200)	-	25 - 30	For firm types of apples.
Baked apples	Ovenproof dish	2 (3)	375 - 390 (190 - 200)	*	20 - 30	Recommendation: use cooking apples, e.g. Boskop. These are especially well-suited for cooking and baking.
						Summer variant: fill with ricotta, lemon, honey, cardamom, vanilla, and pine nuts.
Compote	Glass /	2 (3)	320 - 355	*	30 - 40	e.g. apricots or assorted berries
	grill tray		(160 - 180)			Do not add any liquid, stir several
		2 (3)	390 (200)		30 - 40	times. Season with honey, fresh vanilla or cinnamon.
Clafouti	Ovenproof dish	2 (3)	375 (190)	*	30 - 35	French dessert: classic with cherries, also tastes very good when made with berries or mirabelles.
		2 (3)	390 (200)	♣	55	No need to preheat; do not open appliance door.
Sweet bake	Ovenproof dish	2 (3)	320 - 355 (160 - 180)	*	30 - 40	e.g. semolina, quark or rice pudding
Bread pudding, cherry cake	Ovenproof dish	2 (3)	300 (150)	*	50 - 55	e.g. with cherries or apricots

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Crepes with quark filling	Ovenproof dish	2 (3)	355 - 375 (180 - 190)	*	8 - 10	Austrian specialty: pancakes, filled with quark and raisins, topped with cream and baked.
Meringue	Baking tray + grease- proof paper	2 (3)	210 (100)	*	150	Spread out as flat as possible so that the mass dries all the way through.

Defrosting

- For this, use the "defrost" heating function.
- The defrost values specified are intended as a guide.
 The defrost time depends on the size, weight, and shape of the food to be defrosted: freeze your foods flat or separately. This shortens the defrost time.
- Slide the wire rack with the frozen food into the second shelf level (in the third shelf level if there are five shelf levels). Slide the grill tray underneath to catch any excess liquid.
- Remove the food from the packaging before defrosting.
- Only defrost the quantity that you need right away.
- Please consider: defrosted food will not last as long as frozen food and will spoil more quickly than fresh food. Prepare defrosted food immediately and cook it thoroughly.
- After half the defrost time has elapsed, turn the meat or fish. Separate defrosted food in pieces, e.g. berries or pieces of meat. Fish does not have to defrost all the way; it is sufficient if the surface is soft enough to take up the spices.

 The oven is not suited for defrosting whole chickens and roasts; this takes a long time. It is much faster to defrost such foods in the steam oven.



WARNING

Health risk!

When defrosting food from animal sources, you must remove the liquid that escapes during defrosting. It must never come into contact with other food. Bacteria could be transferred.

Slide the glass/grill tray under the food. Pour away the excess liquid collected from the meat and poultry. Then clean the sink and rinse with plenty of water. Clean the glass/grill tray in hot soapy water or in the dishwasher.

After defrosting, operate the oven for 15 minutes using Hot air at 355°F (180°C).

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Berries (1.1 lb / 500 g)	Glass / grill tray	2 (3)	120–130 (50–55)	* 0	25 - 30	
Vegetables (1.1 lb /500 g)	Glass / grill tray	2 (3)	120–130 (50–55)	* 0	30 - 50	The defrosting time depends on the portioning. Small vegetables such as peas and beans defrost faster than blocks of spinach or whole cauliflower.
Chicken legs (0.4 lb / 200 g each)	Wire rack	2 (3)	120–130 (50–55)	* 0	45 - 50	
Fish fillet (0.3 lb / 150 g each)	Wire rack	2 (3)	115–120 (45–50)	* 0	45 - 50	
Prawns	Wire rack	2 (3)	115–120 (45–50)	* 0	20 - 25	

Preserving

- If possible, cook food immediately after purchase or harvesting. Longer storage decreases the vitamin content and can cause spoilage.
- Only use fruit and vegetables in good condition.
- The oven is not suited for preserving meat.
- Check and clean the canning jars, rubber rings, clamps, and springs carefully.
- Place the canning jars in a heat-resistant container with water. Make sure that they do not touch. The water level must reach at least three quarters of the way up to the top of the contents of the jars.
- Open the cooking compartment door after the cooking time has elapsed. Do not remove the canning jars from the cooking compartment until they have cooled down completely.
- Store the preserves in a cool, dark and dry place, e.g. in a pantry. Once the jars have been opened, use the contents up quickly and store in the refrigerator.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Fruit	Wire rack	1 (2)	300-320 (150-160)		35 - 40	in closed canning jars
Vegetables	Wire rack	1 (2)	375-390 (190-200)		60 - 120	in closed canning jars

Disinfecting

- Before canning, the jars should be disinfected in the oven in order to prevent spoilage. Only this way is it possible to store canned goods for a longer time and outside the refrigerator.
- Disinfect empty jars at 212°F (100°C) hot air for at least 20 minutes. The lids and seals for the jars can be disinfected simultaneously in boiling water so that they do not dry out in the dry heat in the oven.

Dish	Accessories	Level	Temperature in °F (°C)		Cooking time in min.	Observations
Disinfecting	Wire rack	2 (3)	212 (100)	*	20 - 25	Canning jars, baby bottles

Drying

- Drying is a preservation method with which, through the feeding in of dry heat, up to 50% of the liquid in food is removed. At the same time, the flavor becomes more intense.
- The thicker the food is, the longer the drying process takes. Drying is the fastest and most energy-saving method if you want to cut food into slices.
- Place the prepared food on a roasting dish or tray covered with greaseproof paper. During the drying process, turn the food every now and then.
- The duration depends on the thickness of the food and the natural moisture in the food since drying tomatoes takes longer than drying mushrooms.
- If you would like to dry on two levels simultaneously, use levels 1 and 3 (or 2 and 4).

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in hours	Observations
Sliced mushrooms	Wire rack + greaseproof paper	2 (3)	120 - 140 (50 - 60)	*	3 - 4	
Apple rings	Wire rack + greaseproof paper	2 (3)	160 (70)	*	5 - 8	

en-us Tables and tips

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in hours	Observations
Quartered tomatoes	Wire rack + greaseproof paper	2 (3)	140 - 160 (60 - 70)	*	7 - 8	Remove the core from the tomatoes; otherwise the drying time is longer.
Herbs	Wire rack + greaseproof paper	2 (3)	120 - 140 (50 - 60)	*	1½ - 2	e.g. chives, parsley, sage

Baking stone

- You will need a baking stone and heating element these are optional accessories.
- Whether you are baking crispy pizza or fresh bread, with the baking stone, you will achieve results that are comparable to, or even exceed, those that you would get from a massive stone oven because you are able to precisely control the baking temperature.
- Depending on the size, you can also place several pizzas, rolls or other baked goods on the baking stone at the same time.
- You can bake several pizzas in succession. This may increase the baking time per pizza by approx. 1 - 3 minutes.
- When baking bread, we recommend that you use the core temperature sensor. Wait 10 - 15 minutes after baking has begun before inserting the core temperature sensor into the thickest part of the bread. The sensor measures the internal temperature of the baked goods and switches the oven off when the set core temperature has been reached.
- When dough is baked, it needs to be able to expand without the surface breaking apart. This can be achieved by pricking it several times with a fork or by making a cut with a knife.
- The temperatures and times given in the cooking table are guideline values. Always follow the manufacturer's instructions for pre-cooked and frozen products.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Rolls, fresh (1.7 oz /50 g each)	Baking stone	1	480/390* (250/200*)	ww	15-20	
Flatbread	Baking stone	1	140 (210)	ww	15	Cooking time depends on the size and thickness of the flatbread
Foccacia	Baking stone	1	140 (210)	~~	15	Top with various ingredients, e.g. herbs, sea salt, olives, anchovies, onions, ham, tomatoes, or cheese.
Multi-grain bread	Baking stone	1	345 (175)	ww	45	
Sourdough bread	Baking stone	1	480/390* (250/200*)	₩₩.	50-60	
Olive-tomato bread	Baking stone	1	345 (175)	₩₩.	45	
Pizza, fresh	Baking stone	1	525 (275)	ww	5-8	The cooking time varies depending on the type and thickness of the dough and topping.
Pizza, frozen	Baking stone	1	445 (230)	ww	8-10	The cooking time varies depending on the thickness of the dough. Observe the manufacturer's instructions.

^{*} Pre-heat the appliance to the specified temperature. Turn the temperature down when placing the food in the oven.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Comments
Tarte flambée, fresh	Baking stone	1	570 (300)	ww	3-4	Recipe tip: Traditional or with goat's cheese, Parma ham, figs and spring onions.
Tarte flambée, frozen	Baking stone	1	480 (250)	ww	4–5	

^{*} Pre-heat the appliance to the specified temperature. Turn the temperature down when placing the food in the oven.

Roasting dish

- You will need a roaster, pull-out system and heating element – these are optional accessories.
- In the roasting dish, you can also braise large pieces of meat easily and cook large quantities.
- Food is easy to prepare and can be kept warm in the oven. Your kitchen will look clean and tidy, the cooktop will not be dirty, and there will be fewer cooking odors because the dish was cooked in the oven.
- The non-stick coating enables you to roast using very little fat.
 - Tip: Instead of adding the fat to the roasting dish, oil the meat. This ensures that the heat is transferred directly to the meat.
- Cooking liquids reduce down quickly. Make sure there
 is always sufficient cooking liquid. For a cooking time
 of 30 minutes, add approx. ½ I liquid.
- When roasting in a sauce, always ensure the sauce remains runny and add cooking liquid.
- In addition, follow the instructions in the instruction manual for the roasting dish.

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Chicken breast	Roasting dish	1	390 (200)		Searing + 15 - 20	Before inserting the food, also heat the roasting dish with the roasting function. Then insert the core temperature sensor.
Beef goulash	Roasting dish	1	430/265-285* (220/130- 140*)		Searing + 60 - 120	Sear onions and meat; use the roasting setting for this. Pour in liquid and turn heat down, depending on the type of meat, cook for 60 - 120 minutes.
Ossobuco	Roasting dish	1	430/285* (220/140*)		Searing + 60 - 90	Sear meat and vegetables; use the roasting setting for this. Pour in liquid and turn heat down, cook covered for 60 - 90 minutes. Turn once.
Viennese boiled beef	Roasting dish	1	430/265* (220/130*)		Searing + 210 - 240	Sear halved onions, add vegetables briefly and fill up with liquid. Bring to a boil, season, and add beef. The meat should be completely covered with liquid. Put roasting lid on and continue cooking at 265°F (130°C).
Venison ragout	Roasting dish	1	430/265 - 285* (220/130 - 140*)		Searing + 60 - 100	Sear meat and other ingredients; use the roasting setting for this. Pour in liquid and turn heat down, depending on the type of meat and size of the pieces of meat, cook for 60 - 100 minutes.

^{**} Brown the meat at high temperature, switch back to a lower temperature for further cooking.

en-us Tables and tips

Dish	Accessories	Level	Temperature in °F (°C)	Type of heating	Cooking time in min.	Observations
Roulades	Roasting dish	1	430/250* (220/120*)		Searing + 60 - 90	Sear roulades portion by portion; use the roasting setting for this.
Tortillas	Roasting dish	1	345 (175)		Searing + 10 - 15	Sear all ingredients but for the eggs in the roasting dish, then pour the eggs over the top and continue cooking until the tortilla is firm.
Farmers' omelette	Roasting dish	1	345 (175)		Searing + 10 - 15	Sear all ingredients but for the eggs in the roasting dish, then pour the eggs over the top and continue cooking until the farmers' omelette is firm.
Stuffed pep- pers, vegetarian	Roasting dish	1	390 (200)		30	Recipe tip: fill with cooked rice, Ebly wheat or lentils and onions, cheese, herbs and spices.
Chili con carne	Roasting dish	1	430/265* (220 / 130*)		Searing + 60 - 90	

^{**} Brown the meat at high temperature, switch back to a lower temperature for further cooking.

Acrylamide in foodstuffs

Which foods are affected?

Acrylamide is mainly produced in grain and potato products that are heated to high temperatures, such as chips, fries, toast, rolls, bread, fine baked goods (cookies, gingerbread, Christmas spice cookies).

Tips for keepi paring food	ng acrylamide to a minimum when pre-
General	Keep cooking times as short as possible. Cook food until it is golden brown, but not too dark. Large, thick pieces of food contain less acrylamide.
Baking	With hot air at max. 355° F (180 °C).
Cookies	Egg or egg yolk reduces the production of acrylamide. Spread out a single layer evenly on the baking tray.
Oven French fries	Cook at least 400 g at once on a baking tray so that the fries do not dry out.

BSH Home Appliance Corporation 1901 Main Street, Suite 600 Irvine, CA 92614 1-877-442-4436

www.gaggenau.com/us © 2024 BSH Home Appliances



